

Installation Instructions

VOYAGER 2 HAIL GUARD

STEP 1: ATTACH CENTER POST

- 1.1 – ATTACH THE 2 RECTANGULAR BRACKETS TO NEW CENTER POST WITH ½” SCREWS (DETAIL A)
- 1.2 – ASSEMBLE SCREW ASSEMBLIES (FIGURE 1) AND ATTACH TO THE REMAINING HOLES IN THE BRACKETS. THIS IS WHERE THE HAIL GUARDS WILL CONNECT.
- 1.3 – REPLACE OLD CENTER POST ON UNIT WITH NEW ONE.
** NOTE: HEAT PUMP UNITS DO NOT COME STANDARD WITH A CENTER POST. A HOLE MAY NEED TO BE DRILLED IN THE TOP BRACKET FOR OLDER UNIT COMPATIBILITY.*

STEP 2: MARK AND DRILL HOLES IN POSTS

- *SKIP THIS STEP IF POSTS ALREADY HAVE THE NECESSARY HOLES*
- 2.1 – CAREFULLY REST THE RIGHT SIDE HAIL GUARD ON THE CENTER POST. USING A MARKER, MARK A DOT AT THE CENTER OF THE TOP OF THE KEYHOLE ON THE CORRESPONDING POST. THIS WILL BE THE HOLE FOR YOUR SCREW ASSEMBLY. (FIGURE 2)
 - 2.2 – REPEAT THIS MARKING PROCESS FOR THE OTHER CORRESPONDING POST. (FIGURE 3)
 - 2.3 – FOR THE REAR HAIL GUARD, LINE UP THE SIMILAR HOLES FROM THE RIGHT SIDE AND MARK THE LOCATIONS.
 - 2.4 – **BEFORE DRILLING, REMOVE THE POSTS FROM THE UNIT, SO AS NOT TO DAMAGE THE COIL.**
 - 2.5 – DRILL 1/8” HOLES ON THE MARKED LOCATIONS WITH THE PROVIDED SELF TAPPING SCREW.
 - 2.6 – REATTACH THE MODIFIED PANELS WHEN FINISHED.

STEP 3: INSTALL HAIL GUARD

- 3.1 – ASSEMBLE SCREW ASSEMBLIES (FIGURE 1) AND ATTACH TO THE NEW HOLES IN THE POSTS.
- 3.2 – PICK UP THE HAIL GUARD AND ALIGN THE LARGE PART OF THE KEYHOLE WITH THE WASHER. PUSH FORWARD SLIGHTLY TO ENGAGE THE HAIL GUARD WITH THE SPACER, THEN DROP INTO PLACE.

