






# Fan Coil/Force Flo, Blower Coil and Unit Vent with ECM Mtr 1 or Mtr 2 error code "LOCH" on motor board?





Picture 1



Picture 2





Picture 3




Picture 4





Picture 5





Picture 6



Picture 7



Picture 8



Ex: BC fan with driver for ECM motor