



Application Guide

Symbio™ 700 Controller

with Odyssey Split Systems

⚠ SAFETY WARNING

Only qualified personnel should install and service the equipment. The installation, starting up, and servicing of heating, ventilating, and air-conditioning equipment can be hazardous and requires specific knowledge and training. Improperly installed, adjusted or altered equipment by an unqualified person could result in death or serious injury. When working on the equipment, observe all precautions in the literature and on the tags, stickers, and labels that are attached to the equipment.

March 2025

ACC-APG001C-EN

TRANE
TECHNOLOGIES™



Introduction

Read this manual thoroughly before operating or servicing this unit.

Warnings, Cautions, and Notices

Safety advisories appear throughout this manual as required. Your personal safety and the proper operation of this machine depend upon the strict observance of these precautions.

The three types of advisories are defined as follows:



Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.



Indicates a potentially hazardous situation which, if not avoided, could result in minor or moderate injury. It could also be used to alert against unsafe practices.



Indicates a situation that could result in equipment or property-damage only accidents.

⚠ WARNING

Proper Field Wiring and Grounding Required!

Failure to follow code could result in death or serious injury.

All field wiring **MUST** be performed by qualified personnel. Improperly installed and grounded field wiring poses **FIRE** and **ELECTROCUTION** hazards. To avoid these hazards, you **MUST** follow requirements for field wiring installation and grounding as described in NEC and your local/state/national electrical codes.

⚠ WARNING

Personal Protective Equipment (PPE) Required!

Failure to wear proper PPE for the job being undertaken could result in death or serious injury. Technicians, in order to protect themselves from potential electrical, mechanical, and chemical hazards, **MUST** follow precautions in this manual and on the tags, stickers, and labels, as well as the instructions below:

- Before installing/servicing this unit, technicians **MUST** put on all PPE required for the work being undertaken (Examples; cut resistant gloves/sleeves, butyl gloves, safety glasses, hard hat/bump cap, fall protection, electrical PPE and arc flash clothing). **ALWAYS** refer to appropriate Safety Data Sheets (SDS) and OSHA guidelines for proper PPE.
- When working with or around hazardous chemicals, **ALWAYS** refer to the appropriate SDS and OSHA/GHS (Global Harmonized System of Classification and Labelling of Chemicals) guidelines for information on allowable personal exposure levels, proper respiratory protection and handling instructions.
- If there is a risk of energized electrical contact, arc, or flash, technicians **MUST** put on all PPE in accordance with OSHA, NFPA 70E, or other country-specific requirements for arc flash protection, **PRIOR** to servicing the unit. **NEVER PERFORM ANY SWITCHING, DISCONNECTING, OR VOLTAGE TESTING WITHOUT PROPER ELECTRICAL PPE AND ARC FLASH CLOTHING. ENSURE ELECTRICAL METERS AND EQUIPMENT ARE PROPERLY RATED FOR INTENDED VOLTAGE.**

⚠ WARNING**Follow EHS Policies!**

Failure to follow instructions below could result in death or serious injury.

- All Trane personnel must follow the company's Environmental, Health and Safety (EHS) policies when performing work such as hot work, electrical, fall protection, lockout/tagout, refrigerant handling, etc. Where local regulations are more stringent than these policies, those regulations supersede these policies.
- Non-Trane personnel should always follow local regulations.

Copyright

This document and the information in it are the property of Trane, and may not be used or reproduced in whole or in part without written permission. Trane reserves the right to revise this publication at any time, and to make changes to its content without obligation to notify any person of such revision or change.

Trademarks

All trademarks referenced in this document are the trademarks of their respective owners.

Revision History

Updated Table 30 - Outdoor Air Damper Section - Third Alarm



Table of Contents

Introduction.....	7
Additional Documentation.....	7
Symbio™ 700 Overview.....	8
Field Connection.....	8
Unit Configuration.....	9
Onboard User Interface.....	9
Mobile App.....	10
Start-Up Sequence.....	14
Conventional Thermostat Sequence of Operation.....	15
Space Temperature Control Sequence of Operation.....	17
Constant Volume and Multi-Speed Fan Configuration.....	17
Normal Operation.....	17
Supply Fan Control.....	17
Single Zone Variable Air Volume.....	18
Economizer Cooling.....	20
Ventilation Control.....	22
Supply Fan Compensation.....	22
Remote Minimum Position Control.....	22
Demand Controlled Ventilation (DCV).....	22
0 to 50 percent Motorized Damper.....	25
Demand Controlled Ventilation (DCV) — Thermostat Control.....	26
General Support Sequences.....	27
Fan Setpoints with VFD-driven Fan Types.....	27
Compressor Minimum Runtime.....	27
Refrigeration Circuit Management.....	27
Compressor Proof of Operation.....	27
Compressor Low Pressure Cutout Control.....	28
Heat Pump Support Sequences.....	29
Heat Pump Switchover Valve.....	29
Demand Defrost Control.....	29
Evaporator Defrost Control.....	30
Refrigerant Leak Detection System.....	31
Air Handler.....	31
Odyssey Air Handler with VFD Supply Fan.....	31
Condensing Unit.....	32

Building Automation System Support Sequences	33
Occupancy Mode	33
Timed Override	33
Supply Air Tempering	33
Unit Stop	34
Capacity Limit Control	34
Capacity Lockouts	35
Cooling Capacity Enable	35
Heat Primary Enable	35
Demand Limit	35
Remote Capacity Control	36
Emergency and Ventilation Override	36
Ventilation Override (Future)	37
Emergency Override	37
Service Test Mode	38
Service Test Timeout	38
Leaving Service Test Mode	38
Constant Volume Supply Fan Service Test Mode	38
Multi-Speed Supply Fan Service Test Mode	39
Variable Speed Supply Fan Service Test Mode	40
Diagnostics	42
Device Tracker	42
Compressor Proving Diagnostics	42
Diagnostic: Compressor X Proving Trip	42
Diagnostic: Compressor X Proving Lockout	42
Diagnostic: Compressor X Contactor Failure	43
Diagnostics – Low Pressure Cutout	43
Diagnostic: Circuit X LPC Trip	43
Diagnostic: Circuit X LPC Lockout	43
Diagnostics – Alarm Indicator Status	43
Reset Diagnostic	44
Power-Up Reset or Exception/Override Mode Transition	44
Reset Diagnostic Point	44
Heat Cool Mode Transition Reset	44
Reset Diagnostic Point – Active to Inactive Transition	44
Troubleshooting	45
Unit Communication Fault	45
Sensor Fault	45
Compressor Fault	46

VFD Fault	46
Defrost Fault	47
Appendix A	48
Supply Fan	48
Multi-Speed/VFD	48
Variable Speed/VFD	48
Compressor Staging	48
Thermostat Staging	48
Cooling Only (Electric Heat) – CVZT and VVZT	48
Heat Pump – CVZT and VVZT	49
Condenser Fan Operation	49
Thermostat, CVZT, and VVZT	49
Electric Heat	50
CVZT and VVZT	50
Diagnostics and Alarm Indicator Status	50
Emergency and Ventilation Override	52
Internal and External Space Setpoint Adjustment	52
Appendix B	54
Symbio™ 700 Configuration (Odyssey)	54



Introduction

The Symbio™ 700 installed on Odyssey split systems is a factory installed and programmed controller, providing digital control and protection of the equipment.

The Symbio 700 has two model options:

- **Standard Controller** — provides standard troubleshooting via on-board user interface (UI) and access to the Symbio Service and Installation mobile app.
- **Advanced Controller** — introduces additional troubleshooting tools and Building Automation System interface via BACnet® (ANSI/ASHRAE Standard 135-2016), Modbus™, or LonTalk®. Also allows TGP2 and up to eight additional I/O via XM30 or XM32 expansion modules.

The Symbio 700 offers multiple equipment configuration options regardless of controller model. The Odyssey split system can be configured as the following system types:

- Conventional Thermostat Control (T-Stat)
- Space Temperature Control Constant Volume (CVZT)
- Space Temperature Control Single Zone Variable Air Volume (VVZT)

These configurations can be used with standard cooling or heat pump systems.

This guide provides information about the configuration, control capabilities and troubleshooting of the Odyssey system with Symbio 700 controller.

Additional Documentation

- *Symbio™ Service and Installation App, Quick Start Guide* (BAS-SVN043*–EN)
- *Symbio™ 700 Controller, User Guide* (BAS-SVU054*–EN)
- *Symbio™ 700 Integration Points List BACnet®/Modbus™ for Odyssey™* (BAS-PTS005*–EN)
- *Symbio™ 700 Integration Points List LonTalk® for Odyssey™* (BAS-PTS006*–EN)
- *Split System Air Conditioners Odyssey™ with Symbio™ Controls Air Handler — 5 to 25 Tons Installation, Operation, and Maintenance Guide* (SSA-SVX06*–EN)
- *Split System Air Conditioners Odyssey™ with Symbio™ Controls Cooling Condenser, R-410A 5 to 25 Tons Installation, Operation, and Maintenance Guide* (SS-SVX001*–EN)
- *Split System Air Conditioners Odyssey™ with Symbio™ Controls Heat Pump Condenser, R-410A 5 to 20 Tons Installation, Operation, and Maintenance Guide* (SSP-SVX001*–EN)

Symbio™ 700 Overview

Field Connection

The Symbio 700 controller optimizes inputs and outputs (I/O) for multiple applications. For initial installation of an Odyssey with Symbio 700, the field landed inputs are outlined below.

Figure 1. Symbio 700 field connections




Table 1. Field Connections

Connector	Function	Pin #	Signal
J16	Demand Shed/Demand Limit Connection	1	24 Vac
		2	Demand Shed/Demand Limit Input
J17	BACnet Communication Connections	1	BACnet +
		2	BACnet -
		3	BACnet +
		4	BACnet -
J18	Equipment Shutdown Input Connections	1	24 Vac
		2	Equipment Shutdown Input
J19	Zone Sensor Connections	1	Zone Temperature
		2	GND
		3	Cool Setpoint
		4	Mode
		5	Heat Setpoint
		6	GND
		7	24 Vac
J20	Occupancy Connections	1	24 Vac
		2	Occupancy Switch

Table 1. Field Connections (continued)


Connector	Function	Pin #	Signal
J21	Thermostat Connections	1	24 Vac
		2	Y1
		3	W1/O
		4	G
		5	W2
		6	Y2
		7	X2
		8	1.5K Ohms Pull-down
		9	GND
J22	CO ₂	1	24 Vdc Out
		2	CO ₂ In
		3	Common
J23	Space Humidity	1	24 Vdc Out
		2	Space Humidity
		3	Common

Unit Configuration

The Odyssey system can be configured via an onboard user interface or via the Symbio Service and Installation mobile app.

Onboard User Interface

The onboard user interface provides a 2 × 16 Backlit LCD display and navigational buttons. This allows the user to view status, configure, and troubleshoot the unit without additional tools.

Figure 2. Symbio 700 onboard user interface


The interface provides an intuitive menu structure: alarms, status, service, settings, and utilities. Configuration of the unit is accomplished under the utilities menu item. A complete list of functions is outlined in *Symbio™ 700 Controller, User Guide* (BAS-SVU054*-EN).



Symbio™ 700 Overview

To configure the unit, navigate to the utilities menu and press **Enter**. Once in the utilities menu the user has additional submenu options. This allows the user to navigate and configure the appropriate setting quickly and easily.

Mobile App

The Trane Symbio™ Service and Installation mobile app is required to setup, edit, and confirm the communication protocol and associated settings.

The free download of Trane Symbio Service and Installation mobile app is available on the App Store® for iOS, and on Google Play® for Android™.


Figure 3. Trane Symbio service and installation mobile app




Bluetooth Pairing

Quick Connection Instructions

Follow these instructions to quickly connect the mobile app to the Symbio™ 700 controller:

1. Turn on Bluetooth®¹.
2. Tap .
3. Start the app. Tap **View Available Devices**.
4. Select the controller.
5. Tap **OK** to pair.


6. Tap .

Connecting to the Symbio™ 700 controller

1. Enable Bluetooth® on your smart device.
2. Access the Symbio 700 controller in the low voltage portion of the equipment.

¹. The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by the company is under license.

Figure 4. Symbio 700 controller




3. Tap  on Symbio 700 keyboard/display to turn on Bluetooth.
4. Confirm the status of Bluetooth communications. A solid blue LED indicates a successful pairing.

Table 2. Bluetooth communication status




	Blue LED	Display	Description
Tap for On/Off	Off	NOT CONNECTED	Bluetooth Off
	Blinking	WAITING...	Bluetooth On — Not Paired
	On Solid	CONNECTED	Bluetooth On — Connected/ Paired

Figure 5. Symbio 700 bluetooth status




5. Start the mobile app on your smart device.

Figure 6. Login screen


6. On the login screen, tap **View Available Devices** in the lower section of the screen. Or Trane personnel can login using their Trane Connect username and password.
7. On the Unit List page, select the Symbio 700 controller to which you want to pair. If the controller is not listed, tap the refresh arrow in the upper right-hand corner of the screen.


Note: If a Symbio 700 is not the original Symbio controller as shipped with the equipment, the Bluetooth equipment list will list the controller serial number, instead of the equipment serial number.

8. When prompted, pair the app to the Symbio 700 controller. A popup message displays a 6-digit random number. The same number is shown on the display of the Symbio™ 700 controller until the pairing is complete, allowing the user to confirm connection to the intended controller.

Figure 7. Bluetooth pairing


iOS

Android

9. Tap  on the Symbio 700 on-board keyboard/display to complete the connection.

When the LED light is a solid blue and the display reads Bluetooth Connected, the Bluetooth pairing and connection is complete.

Important: To keep the list of previously-connected devices manageable, the Bluetooth smart devices list is limited to 10 devices. When 10 or more Bluetooth devices are defined on the smart device, connection to the Symbio 700 controller is not allowed.

- **iOS devices** - delete any unused devices until there are less than 10 items.
- **Android devices** - the devices list is automatically limited to 10 items.

The Symbio Installation and Service tool is required to view, manage, and configure the following:

- Building Automation System configuration (Advanced Controller Configuration)
 - BACnet® over Zigbee® (Air-Fi® Wireless)
 - BACnet IP (Internet Protocol)
 - BACnet MS/TP
 - LonTalk®
 - Modbus RTU
 - Modbus TCP
- Historical Alarms
- Firmware Update (includes both the Symbio 700 Module and the Options Modules)
- Backing up and Restoring the database
- Transfer Settings from one controller to another
- Return the Symbio 700 to its Factory Default configuration by using the Factory Default Database (if available)
- Update the license file

For more detailed information on the Symbio Service and Installation Mobile Application, refer to *Symbio™ Service and Installation App, Quick Start Guide* (BAS-SVN043*-EN).



Start-Up Sequence

Under normal conditions, the Symbio™ 700 will start-up in approximately 60 seconds once power is applied to the system. During this process, the controller checks that a valid system configuration is present and proceeds to normal control operation. After start-up, the system will begin to respond to operational requests.



Conventional Thermostat Sequence of Operation

When the Odyssey system is configured to operate with a conventional thermostat, the controller provides protection for the system (see “[General Support Sequences](#),” p. 27) and continues to provide insight to operating conditions. A conventional thermostat can be applied with constant volume cooling only, heat pump, and single zone 2-speed fan configured systems. While not recommended, a conventional thermostat can be applied to single zone variable volume configured systems, but the system is limited to staged fan control instead of a fully variable sequence.

When under conventional thermostat control, the equipment responds directly to operating requests from the thermostat device. Each thermostat input corresponds to a specific unit function, as described in the following tables. Equipment protection functions and compressor minimum on/off timers remain in-control, even when under conventional thermostat control.

Table 3. Cooling only/electric heat systems

Inputs						Outputs				
X	Y1	Y2	W1/O	W2	G	Supply Fan On/Off Request	Supply Fan Speed Request	Compressor Cool Stage Request	Auxiliary Heat Stage Request	Heat Cool Mode Status
—	OPEN	OPEN	OPEN	OPEN	CLOSED	ON	Min	None	None	Fan Only
—	OPEN	OPEN	CLOSED	OPEN	X	ON	Max	None	Stage 1	Heat
—	OPEN	OPEN	X	CLOSED	X	ON	Max	None	Full Stage	Heat
—	CLOSED	OPEN	OPEN	OPEN	X	ON	Min	Stage 1	None	Cool
—	OPEN	CLOSED	OPEN	OPEN	X	ON	Min	Stage 1	None	Cool
—	CLOSED	CLOSED	OPEN	OPEN	X	ON	Max	Full Stage	None	Cool
—	X	X	X	X	X	OFF	0	None	None	OFF

X=ignored by controller

Conventional Thermostat Sequence of Operation

Table 4. Heat pump systems

Inputs						Outputs					
X	Y1	Y2	W1/O	W2	G	Supply Fan On/Off Request	Supply Fan Speed Request	Compressor Cool Stage Request	Compressor Heat Stage Request	Auxiliary Heat Stage Request	Heat Cool Mode Status
CLOSED	OPEN	OPEN	OPEN	OPEN	X	ON	Max	None	None	Full Stage	Em Heat
OPEN	CLOSED	OPEN	OPEN	OPEN	X	ON	Max	None	Stage 1	None	Heat
OPEN	OPEN	CLOSED	OPEN	OPEN	X	ON	Max	None	Stage 1	None	Heat
OPEN	CLOSED	CLOSED	OPEN	OPEN	X	ON	Max	None	Full Stage	None	Heat
OPEN	CLOSED	OPEN	OPEN	CLOSED	X	ON	Max	None	Stage 1	Full Stage	Heat
OPEN	OPEN	CLOSED	OPEN	CLOSED	X	ON	Max	None	Stage 1	Full Stage	Heat
OPEN	CLOSED	CLOSED	OPEN	CLOSED	X	ON	Max	None	Full Stage	Full Stage	Heat
OPEN	X	X	OPEN	CLOSED	X	ON	Max	None	None	Full Stage	Heat
OPEN	OPEN	OPEN	CLOSED	OPEN	OPEN	OFF	0	None	None	None	Cool
OPEN	CLOSED	OPEN	CLOSED	OPEN	X	ON	Min	Stage 1	None	None	Cool
OPEN	OPEN	CLOSED	CLOSED	OPEN	X	ON	Min	Stage 1	None	None	Cool
OPEN	CLOSED	CLOSED	CLOSED	OPEN	X	ON	Max	Full Stage	None	None	Cool
OPEN	OPEN	OPEN	X	OPEN	CLOSED	ON	Min	None	None	None	Fan Only
X	X	X	X	X	X	OFF	0	None	None	None	OFF

X=ignored by controller



Space Temperature Control Sequence of Operation

Constant Volume and Multi-Speed Fan Configuration

Normal Operation

The Symbio™ 700 has a single-loop (space temperature only) control sequence. The sequence is PI-based (proportional, integral) and strives to maintain space temperature within 1° F of the active cooling and heating setpoints.

- When Space Temperature Active > Space Temp Cooling Setpoint Status, the algorithm calculates a need for cooling capacity to be energized.
- When Space Temperature Active < Space Temp Heating Setpoint Status, the algorithm calculates a need for heating capacity to be energized.
- When Space Temp Heating Setpoint Status ≤ Space Temperature Active ≤ Space Temp Cooling Setpoint Status:
 - The algorithm calculates a reduction in need for any active cooling or heating capacity if ON.
 - If no cooling or heating capacity is active, cooling and heating capacity remains inactive.


Supply Fan Control

The supply fan is controlled "ON" 5 seconds before heating or cooling capacity is energized. When heating or cooling capacity is de-energized, a supply fan off delay is applied based on active capacity. For single-speed supply fan configured systems, the supply fan is controlled "ON" during all cooling and heating sequences.

For multi-speed supply fan configured systems, the fan operates per the following:

- Low speed when the supply fan is ON without active capacity (unless ON due to an override function).
- Low speed when the unit is operating at its minimum cooling stage.
- High speed when the unit is operating at its maximum cooling stage or while any heating stages are active.

Figure 8. Multi-speed fan sequence of operation



Single Zone Variable Air Volume

When configured for VVZT (also known as SZVAV) control, the sequence is only applicable when the following are true; otherwise, the CVZT sequence is leveraged:

- When Occupancy Status is Occupied and
- When Supply Fan Configuration Status is Continuous and
- When Discharge Air Temperature sensor is not in an Alarm state and
- The unit is operating under a cooling demand (VVZT heating is not applicable with staged heat for Odyssey)

The sequence is PI-based (proportional, integral) and strives to maintain space temperature within 1° F of the Active Cooling and Heating setpoints.

When Space Temperature Active > Space Temp Cooling Setpoint status, the algorithm calculates a need for cooling capacity to be energized. A discharge air temperature setpoint calculates lower to determine proper compressor staging needs. The minimum value of this calculated setpoint for temperature control can be adjusted by the Discharge Air Temperature Minimum Cool Limit setpoint.

When Space Temperature Active < Space Temp Cooling Setpoint status, the algorithm calculates a reduction in need for cooling capacity to be energized. A discharge air temperature setpoint calculates higher to determine proper compressor staging needs. The maximum value of this calculated setpoint for temperature control can be adjusted by the Discharge Air Temperature Maximum Cool Limit setpoint.

Different from the CVZT sequence, compressors are staged to maintain the discharge air temperature at the Discharge Air Temperature Setpoint Active setpoint.

VVZT DAT Control Mode

With the Symbio™ 700 VVZT control sequence, the end user can choose to use the internally derived Discharge Air Temperature Setpoint Active or to override the value with their own.

If the VVZT DAT Control Mode – Active point is set to "Auto", the VVZT control algorithm will use the internally derived Discharge Air Temperature Setpoint Active, as described above, for all cooling capacity output control.

If the VVZT DAT Control Mode – Active point is set to "Manual", the VVZT control algorithm will use the Discharge Air Cooling Setpoint (Target) – Active as upper limit for the Discharge Air Temperature Setpoint calculation. Typically this is set to a low value (i.e 50 to 55° F) to drive longer compressor runtimes. When this override is active, if the space temperature is 2° F below the Space Temp Cooling Setpoint Status value or 1° F above the Space Temp Heating Setpoint Status value, the controller will pause the override sequence until the space temperature recovers to above the Space Temp Cooling Setpoint status.


Supply Fan Control

For the VVZT control sequence to be active, the Supply Fan Configuration Status must be ON/Continuous.

The fan speed is continuously variable on VVZT systems. The fan remains at minimum speed (based on active compressor stages) until the space demand requires additional airflow.

All heating is accomplished with the CVZT control sequence, and the fan is controlled at maximum speed.

Figure 9. Supply fan sequence of operation





Economizer Cooling

Symbio™ 700 supports a 0 to 100 percent economizer damper which requires a discharge air temperature sensor to be installed for economizer cooling. There are four configurable economizer types: fixed dry bulb, differential dry bulb, reference enthalpy, and comparative enthalpy. Each type, enable, and the high limit disable criteria are defined as follows.

Table 5. Economizer types

Type	Economizer Status	Calculation
Fixed Dry Bulb	Enable	Outdoor Air Temperature < Economizer Outdoor Air Enable Setpoint – Economizer Dry Bulb Enable Offset
	Disable	Outdoor Air Temperature > Economizer Outdoor Air Enable Setpoint
Differential Dry Bulb	Enable	Outdoor Air Temperature < (Return Air Temperature - Economizer Dry Bulb Enable Offset - Economizer Dry Bulb Disable Return Air Offset)
	Disable	Outdoor Air Temperature < (Return Air Temperature - Economizer Dry Bulb Disable Return Air Offset)
Reference Enthalpy	Enable	Outdoor Air Enthalpy < (Economizer Outdoor Air Enthalpy Enable Setpoint – Economizer Cooling Reference Enthalpy Offset) AND Outdoor Air Temperature < (Economizer Outdoor Air Enable Setpoint – Economizer Dry Bulb Enable Offset)
	Disable	Outdoor Air Enthalpy > Economizer Outdoor Air Enthalpy Enable Setpoint OR Outdoor Air Temperature > Economizer Outdoor Air Enable Setpoint
Comparative Enthalpy	Enable	Outdoor Air Enthalpy < (Return Air Enthalpy – Economizer Cooling Reference Enthalpy Hysteresis Offset) AND Outdoor Air Temperature < (Economizer Outdoor Air Enable Setpoint - Economizer Dry Bulb Enable Offset)
	Disable	Outdoor Air Enthalpy > Return Air Enthalpy OR Outdoor Air Temperature > Economizer Outdoor Air Enable Setpoint

While the configuration parameters will be used to determine which method of economizer control will be utilized, the table below describes the needed sensor data for each control method.

Table 6. Sensor data

Economizer Enable Method	Required Sensor Data
Comparative Enthalpy	Outdoor Air Temperature
	Outdoor Air Humidity
	Return Air Temperature
	Return Air Humidity
Reference Enthalpy	Outdoor Air Temperature
	Outdoor Air Humidity
Dry Bulb	Outdoor Air Temperature

Table 6. Sensor data (continued)

Economizer Enable Method	Required Sensor Data
Differential Dry Bulb	Outdoor Air Temperature
	Return Air Temperature

When conditions are suitable for economizer operation, the outdoor air damper modulates between a calculated outdoor air damper minimum position (based on Supply Fan Compensation and Demand Controlled Ventilation) and 100 percent open. Economizing will not allow additional mechanical cooling until the damper position is 100 percent and supply fan has reached 100 percent capacity for 5 minutes. If economizer cooling becomes disabled, the damper will revert to minimum position control, and transition to mechanical cooling.

A building automation system can directly command economizer operation via Economizer Airside Enable (auto, enable, disable). If commanded Enable, the controller will start economizer cooling, regardless of outdoor air conditions. If commanded Disable, economizer cooling will be disabled (except if a mode of Night Purge is commanded to the controller). If commanded Auto, the controller will use the configured Economizer high limit method and input values to determine if economizer cooling is available.



Ventilation Control

On equipment installed with a 0 to 100% Economizer or 0 to 100% Economizer w/Traq, the Symbio™ 700 will control the outdoor air damper to provide minimum ventilation requirements based on the specific options installed, enabled features and mode of operation. During normal occupied periods of heating and cooling modes of operation, the outdoor air damper maintains ventilation requirements. However, the following modes of operation will override the damper minimum position setpoint to 0%.

- Morning Warm-up
- PreCool
- Night Purge
- Unoccupied Heat
- Unoccupied Cool
- Off

Supply Fan Compensation

The outdoor air damper minimum position is modulated to provide outdoor air based on supply fan speed. When the supply fan increases speed, the outdoor air damper minimum position is reduced to prevent over ventilation. When the supply fan decreases speed the outdoor air damper minimum position is increased to maintain design outdoor air requirements. There are three user editable design minimum settings to linearize damper position with the fan curve during Occupied and Occupied Bypass modes of operation.

- Design Minimum OA Damper Position at Min Fan Capacity (25 percent default)
- Design Minimum OA Damper Position at Mid Fan Capacity (15 percent default)
- Design Minimum OA Damper Position at Full Fan Capacity (10 percent default)

There are three additional user editable design minimum settings for Occupied-Standby mode of operation.

- Standby Minimum OA Damper Position at Min Fan Capacity (25 percent default)
- Standby Minimum OA Damper Position at Mid Fan Capacity (15 percent default)
- Standby Minimum OA Damper Position at Full Fan Capacity (10 percent default)

Remote Minimum Position Control

With an installed Customer Connection Module and Remote Minimum Position is configured in the Symbio™ 700, a wired potentiometer can be used to adjust the outdoor air damper minimum position setpoint in the range of 0 to 50% (0 to 270 ohms). The setting is reported via Remote Minimum Position. If Remote Minimum Position input and Demand Controlled Ventilation is installed, the Remote Minimum Position provides the minimum damper position setpoint at full fan capacity. Tables below provide details of when the Remote Minimum Position input is utilized in minimum ventilation control.

When Remote Minimum Position is installed with Demand Controlled Ventilation, the Remote Minimum Position input is used in place of Design Minimum OA Damper Position at Full Fan Capacity setpoint. See tables below for more details.

Demand Controlled Ventilation (DCV)

Demand controlled ventilation reduces energy consumption by reducing the outdoor air damper below design minimum ventilation based on space CO₂. When Demand Controlled Ventilation is configured and Supply Fan Compensation is enabled, DCV resets the outdoor air damper minimum position based on space CO₂ and supply fan speed. Decreasing CO₂ levels will decrease damper position below the Design Minimum toward the DCV minimum damper position setpoint. Increasing CO₂ level will increase damper position toward design minimum setpoint. DCV requires a valid space CO₂ value from a building management system or wired sensor. If Space CO₂ value is invalid or Supply Fan Compensation is disabled, the Symbio™ 700 will revert to Outdoor Air Minimum Position Control.

Demand controlled ventilation setpoints used in all methods.

- Space CO₂ High Limit
- Space CO₂ Low Limit

Occupied and Occupied-Bypass mode. If the supply fan is at 100 percent and CO₂ is at the Space CO₂ High Limit (1500 ppm default), the outdoor air damper will be positioned at Design Minimum OA Damper Position at Full Fan Capacity (10 percent default). As CO₂ in the space reduces below the high limit, the outdoor air damper will close. If CO₂ falls below the Space CO₂ Low Limit, the damper position will be at DCV Minimum OA Damper Position at Full Fan Capacity (5 percent default).

Occupied-Standby mode. The damper will reset, based on CO₂, between the Standby Minimum OA Damper Position at Full/Mid/Min Fan Capacity and DCV Minimum OA Damper Position at Full/Mid/Min Fan Capacity.

The following tables define the Symbio 700 setpoints for Demand Controlled Ventilation control, which depend on the features enabled and configuration options installed. Each table is based on the supply fan and damper type installed. Supply Fan Compensation is a feature that can be enabled or disabled. Demand Controlled Ventilation and Remote Minimum Position are Symbio 700 configurations.

Table 7. 0 to 100 percent economizer – variable speed supply fan

Supply Fan Compensation	Demand Controlled Ventilation	Remote Minimum Position	Occupancy Status	Outdoor Air Damper Controlling Setpoints
Enabled	Installed	Installed	Occupied, Occupied Bypass	Remote Minimum Position (Full Fan Capacity) Design Minimum OA Damper Position at Mid Fan Capacity Design Minimum OA Damper Position at Min Fan Capacity DCV Minimum OA Damper Position at Full Fan Capacity DCV Minimum OA Damper Position at Mid Fan Capacity DCV Minimum OA Damper Position at Min Fan Capacity
Enabled	Installed	Not Installed	Occupied, Occupied Bypass	Design Minimum OA Damper Position at Full Fan Capacity Design Minimum OA Damper Position at Mid Fan Capacity Design Minimum OA Damper Position at Min Fan Capacity DCV Minimum OA Damper Position at Full Fan Capacity DCV Minimum OA Damper Position at Mid Fan Capacity DCV Minimum OA Damper Position at Min Fan Capacity
Enabled	Not Installed or Disabled	Installed	Occupied, Occupied Bypass	Remote Minimum Position (Full Fan Capacity) Design Minimum OA Damper Position at Mid Fan Capacity Design Minimum OA Damper Position at Min Fan Capacity
Enabled	Not Installed or Disabled	Not Installed	Occupied, Occupied Bypass	Design Minimum OA Damper Position at Full Fan Capacity Design Minimum OA Damper Position at Mid Fan Capacity Design Minimum OA Damper Position at Min Fan Capacity
Enabled	Installed	Installed or Not Installed	Occupied Standby	Design Minimum OA Damper Position at Full Fan Capacity Design Minimum OA Damper Position at Mid Fan Capacity Design Minimum OA Damper Position at Min Fan Capacity Standby Minimum OA Damper Position at Full Fan Capacity Standby Minimum OA Damper Position at Mid Fan Capacity Standby Minimum OA Damper Position at Min Fan Capacity



Ventilation Control

Table 7. 0 to 100 percent economizer – variable speed supply fan (continued)

Supply Fan Compensation	Demand Controlled Ventilation	Remote Minimum Position	Occupancy Status	Outdoor Air Damper Controlling Setpoints
Disabled	Installed or Not Installed	Installed or Not Installed	Occupied, Occupied Bypass, Occupied Standby	Economizer Minimum Position Setpoint

Table 8. 0 to 100 percent economizer – multi-speed supply fan (2-speed)

Supply Fan Compensation	Demand Controlled Ventilation	Remote Minimum Position	Occupancy Status	Outdoor Air Damper Controlling Setpoints
Enabled	Installed	Installed	Occupied, Occupied Bypass	Supply Fan at 100%: Remote Minimum Position DCV Minimum OA Damper Position at Full Fan Capacity Supply Fan at minimum speed: Design Minimum OA Damper Position at Min Fan Capacity DCV Minimum OA Damper Position at Min Fan Capacity
Enabled	Installed	Not Installed	Occupied, Occupied Bypass	Supply Fan at 100%: Design Minimum OA Damper Position at Full Fan Capacity DCV Minimum OA Damper Position at Full Fan Capacity Supply Fan at minimum speed: Design Minimum OA Damper Position at Min Fan Capacity DCV Minimum OA Damper Position at Min Fan Capacity
Enabled	Not Installed or Disabled	Installed	Occupied, Occupied Bypass	Supply Fan at 100%: Remote Minimum Position Supply Fan at minimum speed: Design Minimum OA Damper Position at Min Fan Capacity
Enabled	Not Installed or Disabled	Not Installed	Occupied, Occupied Bypass	Supply Fan at 100%: Design Minimum OA Damper Position at Full Fan Capacity Supply Fan at minimum speed: Design Minimum OA Damper Position at Min Fan Capacity
Enabled	Installed	Installed or Not Installed	Occupied Standby	Supply Fan at 100%: Standby Minimum OA Damper Position at Full Fan Capacity DCV Minimum OA Damper Position at Full Fan Capacity Supply Fan at minimum speed: Standby Minimum OA Damper Position at Min Fan Capacity DCV Minimum OA Damper Position at Min Fan Capacity

Table 8. 0 to 100 percent economizer – multi-speed supply fan (2-speed) (continued)

Supply Fan Compensation	Demand Controlled Ventilation	Remote Minimum Position	Occupancy Status	Outdoor Air Damper Controlling Setpoints
Enabled	Not Installed or Disabled	Installed or Not Installed	Occupied Standby	Supply Fan at 100%: Standby Minimum OA Damper Position at Full Fan Capacity Supply Fan at minimum speed: Standby Minimum OA Damper Position at Min Fan Capacity
Disabled	Installed or Not Installed	Installed or Not Installed	Occupied, Occupied Bypass, Occupied Standby	Economizer Minimum Position Setpoint BAS

Table 9. 0 to 100 percent economizer – single-speed supply fan

Supply Fan Compensation	Demand Controlled Ventilation	Remote Minimum Position	Occupancy Status	Outdoor Air Damper Controlling Setpoints
Enabled	Installed	Installed	Occupied, Occupied Bypass	Remote Minimum Position DCV Minimum OA Damper Position at Full Fan Capacity
Enabled	Installed	Not Installed	Occupied, Occupied Bypass	Design Minimum OA Damper Position at Full Fan Capacity DCV Minimum OA Damper Position at Full Fan Capacity
Enabled	Not Installed	Installed	Occupied, Occupied Bypass	Remote Minimum Position
Enabled	Not Installed	Not Installed	Occupied, Occupied Bypass	Design Minimum OA Damper Position at Full Fan Capacity
Enabled	Installed or Not Installed	Installed or Not Installed	Occupied Standby	Standby Minimum OA Damper Position at Full Fan Capacity DCV Minimum OA Damper Position at Full Fan Capacity
Disabled	Installed or Not Installed	Installed or Not Installed	Any	Economizer Minimum Position Setpoint BAS

0 to 50 percent Motorized Damper

When a 0 to 50 percent motorized damper is installed, with any supply fan type, the outdoor air damper is controlled to a setpoint from a Remote Minimum Position (wired input), Motorized Damper Position Setpoint, or Economizer Minimum Position Setpoint BAS. The following table summarizes which setpoint is in control of the damper position based on options installed and enabled.

Table 10. 0 to 50 percent motorized damper

Supply Fan Compensation	Remote Minimum Position	Occupancy Status	Outdoor Air Damper Controlling Setpoints
Enabled	Installed	Any	Remote Minimum Position
Enabled	Not Installed	Any	Motorized Damper Position Setpoint
Disabled	Installed or Not Installed	Any	Economizer Minimum Position Setpoint BAS



Demand Controlled Ventilation (DCV) — Thermostat Control

When the Symbio™ 700 is configured for Conventional Thermostat Control, 0 to 100 percent Economizer Damper and Demand Controlled Ventilation (Installed), the controller provides an Occupancy binary input that can be used to control Occupied and Unoccupied modes of operation. In Unoccupied mode, DCV is disabled, and the outdoor air damper minimum position is effective 0 percent. In Occupied mode, DCV will control the outdoor air damper based on Space CO₂ while the supply fan is ON, as described in the previous sections.

In Occupied mode, if the supply fan cycles OFF, the controller will continue to monitor Space CO₂. If Space CO₂ exceeds the Space CO₂ High Limit setpoint for 15 minutes, the supply fan will turn ON and operate at minimum speed and outdoor air damper at the Design Minimum OA Damper Position. If Space CO₂ falls below the Space CO₂ High Limit – 200 ppm, the supply fan will cycle OFF. The supply fan will also cycle off if occupancy changes to Unoccupied.



General Support Sequences

Fan Setpoints with VFD-driven Fan Types

When a system is equipped with a VFD, the minimum and maximum VFD parameters can be adjusted to tune the airflow to meet the application requirements.

In addition to this, the Symbio™ 700 supports setpoints that can adjust airflow as needed:

- Supply Fan Maximum Speed Setpoint
 - Range: 67 to 100%
 - Operation: This setpoint “trims” the maximum fan speed, based on the configured maximum VFD speed
 - Example: VFD Max = 60Hz
 - Supply Fan Maximum Speed Setpoint @ 75% yields a maximum of 45Hz VFD output.
 - Effective VFD Max (to be used in Supply Fan Minimum Speed Setpoint application) will be set to 45Hz
- Supply Fan Minimum Speed Setpoint
 - Range: 0 to 100%
 - Operation: 0 to 100% over minimum to effective maximum VFD configured fan speed
 - Example: VFD Min = 30Hz, Effective VFD Max = 60Hz
 - Supply Fan Minimum Speed Setpoint @ 50% yields 45Hz VFD output.
- Minimum and Maximum Speed Setpoints interact to ensure that the minimum defined fan speed at a given equipment operating condition is maintained.

Compressor Minimum Runtime

Under all normal running conditions, a 3-minute minimum ON and OFF timer is maintained for each compressor. Once a compressor is turned ON, it remains on for a minimum of 3 minutes. Once a compressor is turned OFF, it remains off for a minimum of 3 minutes. System overrides that require immediate shutdown of the equipment, test modes, and compressor diagnostics/protection functions can override these 3-minute timers. However for normal temperature and thermostatic-based control, these minimum ON/OFF timers are maintained.

Refrigeration Circuit Management

There are two refrigeration configurations that the controller will use to determine proper response to refrigeration system faults:

- When the unit is configured with a **Manifold** refrigeration system, if any compressor protection device or function trips for a given compressor, all compressors associated with the circuit on which the protection device or functions trips will be commanded to OFF.
- When the unit is configured with an **Independent** refrigeration system, if any compressor protection device or function trips, for a given compressor, only the compressor associated with the protection device or function that tripped will be commanded to OFF.

Compressor Proof of Operation

For each compressor, a Compressor Proving binary input is used to monitor the state of an auxiliary switch that is used to indicate compressor motor contactor status. Under normal operation, detected operation indicates that all safety devices within the compressor safety circuit are in their normal state. The switch operates as OPEN when the compressor motor is OFF and CLOSED when the compressor motor is ON.

See “[Diagnostics](#),” p. 42 for specific diagnostics that are generated based on the Compressor Proving signals.



Compressor Low Pressure Cutout Control

For each compressor/circuit, a normally CLOSED low pressure cutout input is monitored for equipment protection on the Symbio 700. When a low pressure event is active, the input becomes OPEN and diagnostics are generated as described below. See [“Diagnostics,” p. 42](#) for specific diagnostics that are generated based on the circuit Low Pressure Cutout inputs.

Heat Pump Support Sequences

Heat Pump Switchover Valve

The Switchover Valve function is only applicable to Heat Pump units. Depending on the refrigeration system configuration for a unit, it may have one or two switchover valves. Additionally, some units with two switchover valves could control each valve independently while others will control in tandem.

In normal unit operation, the Unit Mode will determine the operation of the switchover valve. Unit Mode COOL will turn the switchover valve ON while Unit Mode HEAT will turn the switchover valve OFF.

If the unit is in active Heat Pump Heating (switchover valve is OFF) and then enters defrost, the switchover valve will be turned ON for the duration of defrost. When leaving active defrost, the switchover valve transition to OFF is delayed 5 seconds.

Demand Defrost Control


There are two schemes in common usage for heat pump outdoor coil defrosting: Demand Defrost and time temperature defrost. Demand Defrost is more efficient because defrost cycles are initiated only when necessary, compared with initiation based on operating time below the threshold temperature.

Outdoor coil defrosting occurs only when operating in heating mode with outdoor ambient temperature below 52° F and the outdoor coil temperature below 33° F. The first defrost cycle after power-up is initiated based on operating time at the required conditions. Shortly after completion of the defrost cycle, the temperature difference between the outdoor coil and outdoor air is calculated and is used as an indicator of unit performance at dry coil conditions.

Over time, as moisture and frost accumulate on the coil, the coil temperature will drop, increasing the temperature difference. When the temperature difference reaches 1.8 times the dry coil temperature differential (ΔT), a defrost cycle is initiated. While defrosting, the reversing valve is in the cooling position, outdoor fans are off, and the compressors continue to operate.

The defrost cycle is terminated when the coil temperature rises high enough to indicate that the frost has been eliminated. Termination of the defrost cycle includes a soft start delay. At the end of each defrost cycle, the outdoor fan comes on 5 seconds before the reversing valve is de-energized. This reduces stress on the compressor and makes for a quieter defrost.

Figure 10. Typical demand defrost cycle



During the defrost cycle, the Switchover Valve is turned ON, the Condenser Fan is turned OFF, and auxiliary heat is turned ON regardless of their prior operating status while maintaining compressor operation. The defrost cycle is terminated based on the defrost termination temperature calculation using the outdoor temperature (ODT) +47°F. The defrost termination temperature (DTT) will be limited between 57° F and 72° F.



Evaporator Defrost Control

To prevent frost build-up on the indoor coil during low ambient conditions, compressor operation is monitored and controlled accordingly, relative to outdoor air temperature.

Evaporator Defrost Control can be initiated through two means, based on configuration.

- If configured for Evaporator Defrost Control Enabled:
 - When the unit is operating in a “Cool” mode with a valid Outdoor Air Temperature, the EDC function will keep track of the amount of time that at least one compressor in the unit is commanded ON and the Outdoor Air Temperature Active is less than the low ambient temperature defined in . If the Accumulated Compressor On Time reaches 10 minutes, the EDC function will cause the Compressor Output(s) to de-energize for three minutes. The supply fan continues to operate during this 3-minute interval at 100 percent capacity. After the 3-minute EDC timer has expired, the EDC function is ended and compressors are allowed to operate as requested by the algorithm.
 - Low Ambient Temperature Setpoints:
 - Single Compressor Systems: 55° F
 - Multi-Compressor Systems: 40° F
- If configured for FroStat Installed:
 - A FroStat input can also be used to directly request the Evaporator Defrost Control function
 - When the unit is running in an effective “Cool” mode, the FroStat input will directly control the FroStat diagnostic. If the FroStat input CLOSES, the diagnostic will be annunciated.
 - When the unit is running in an effective “Heat” mode, and the Refrigeration System == Heat Pump, the FroStat diagnostic will be controlled “Inactive” until the following are true:
 - FroStat input is CLOSED
 - One or More Compressors have been active for Heat Pump Heating for more than 30 seconds.

Once the above two conditions are met, the FroStat Diagnostic will become Active.

 - The FroStat diagnostic is an Auto-Reset diagnostic such that it will be reset when the FroStat input is OPEN in either effecting unit mode.
 - If the FroStat diagnostic becomes active, the Compressor Output(s) will de-energize until the FroStat diagnostic is cleared. The supply fan continues to operate during the FroStat diagnostic, so long as it is still requested by a heating or cooling function.

FroStat and Evaporator Defrost Control can both be configured on a unit, although in most cases, only one should be necessary.



Refrigerant Leak Detection System

Air Handler

Odyssey R-454B refrigerant air handlers are equipped with factory-installed leak detection system (LDS) and wired to relay board terminals (J12, J13). The refrigerant sensors are designed to detect the presence of refrigerant in the air handlers. When operating normally and not detecting refrigerant, the sensor binary output is closed, providing a 24 Vac signal to the relay board through terminals J12-3 and J13-3. If either sensor detects a refrigerant concentration above a predetermined threshold, the sensor output opens, removing the 24 Vac signal to the relay board input. This indicates an alarm state. During an alarm condition, the relay board initiates the following mitigation actions:

- Supply fan operates continuously to ensure proper airflow and ventilation.

- Electric heat operation is disabled.

The relay board also provides additional hardware outputs that are important for system monitoring and integration. The following table details these outputs, along with their recommended wiring configurations.

Table 11. Relay board outputs

Relay Board Terminal	Type	Leak Detection System	Description
J14-1, J14-2 [VENT]	N.O. Dry Contact, Binary Output	Normal	Dry contact binary output is open.
		Alarm	Binary output closed. Can be used to signal an independent ventilation system to provide additional ventilation.
J14-3, J14-4 [ALARM]	N.O. Dry Contact, Binary Output	Normal	Dry contact binary output is closed indicating the refrigerant sensor is operating normal and not measuring a concentration of refrigerant above a specified threshold.
		Alarm	Dry contact binary output is open indicating the refrigerant sensor detecting refrigerant above a threshold. After the refrigerant concentration reduces below a threshold, the alarm state will continue for 5 additional minutes. The Alarm state is also active if the refrigerant sensor fails. The alarm state remains active until the sensor is replaced.
J14-5 Y1o	N.O. 24 Vac, binary output	Normal	Binary output is open, 0 Vac at the output.
		Alarm	Binary output is closed, providing 24 Vac. To be utilized as compressor disabling signal to Electromechanical condensing units when air handler Refrigerant Sensor is in alarm. The output is intended to drive an isolation relay coil to minimize VA consumption.
J14-6 Y2o	N.O. 24 Vac, binary output	Normal	Binary output is open, 0 Vac at the output.
		Alarm	Binary output is closed, providing 24 Vac. To be utilized as compressor disabling signal to Electromechanical condensing units when air handler Refrigerant Sensor is in alarm. The output is intended to drive an isolation relay coil to minimize VA consumption.

Odyssey Air Handler with VFD Supply Fan

When an Odyssey air handler with a VFD is paired with an Odyssey condenser with Symbio™ 700 in an application using the following capabilities, it may be necessary to remove the wire harness to the VFD drive jog input. By removing the VFD jog input wiring to the relay board, the VFD will be controlled by the Symbio 700 condensing unit in all modes of operation, including when the leak detection system has an active alarm.

If the Odyssey unit operates in a building fire and smoke system using the Symbio 700 emergency override functionality or wired connections for ventilation override functions, the VFD jog input wiring should be removed. This will allow the building fire and smoke system to override the leak detection system.



Refrigerant Leak Detection System

If the Odyssey unit has devices wired to the Symbio 700 emergency stop input or customer option module external auto/stop input and these devices are required to override the leak detection system, the VFD jog input wiring should be removed.

Condensing Unit

The Odyssey condensing units equipped with R-454B refrigerant feature a terminal block for connecting a refrigerant detection system input. This input is wired to the Symbio 700 terminal P21. The refrigerant detection system input is a normally closed, binary input. When the input is in the normal position (closed), the condensing unit operates normally for heating, cooling, and ventilation. However, if the binary input is in the alarm position (open), it indicates that the measured refrigerant concentration has exceeded a predetermined threshold. In response, the Symbio 700 controller initiates mitigation actions for the duration of the alarm condition.

Mitigation actions implemented by the Symbio 700:

- All compressor operation is disabled.
- The supply fan is requested to operate continuously.
- All heating, cooling, and ventilation operation is disabled.
- Alarm output energizes on the Customer Options Module (if installed).

The following Symbio 700 points related to the refrigerant detection system are available on the BACnet® or Modbus™ interface, but not on the LonTalk® interface. These points enable monitoring and coordination with other building systems.

Table 12. Refrigerant leak detection system points

Point Reference	Description
Refrigerant Leak Detection System Input	The Active state is maintained for the duration of the refrigerant detection system alarm state.
Refrigerant Mitigation Active	This point indicates whether the Symbio controller is in a refrigerant mitigation state. It can be utilized for coordinating actions with other building systems.
Diagnostic: Refrigerant Concentration Sensor A	Active when Refrigerant Leak Sensor is in the alarm state. Resets to inactive when the Refrigerant Leak Sensor alarm has reset; refrigerant concentration has reduced below the lower concentration threshold.



Building Automation System Support Sequences

Occupancy Mode

During expected occupied periods, the system will control to the user selected cooling and heating setpoints.

- The unoccupied setpoint temperatures are often adjusted higher for cooling (setup) and lower for heating (setback) to reduce building operating cost.
- Regardless of how the (occupied) fan mode is set, the supply fan mode is forced to AUTO during unoccupied periods to reduce supply fan operating costs.

There are two mechanisms available to control when units should switch between occupied and unoccupied modes:

- Building controllers provide signals to the unit to request occupied or unoccupied operation. Time-of-day scheduling within building controllers typically determine when the switching should occur.
- Stand Alone Unoccupied control is initiated by a contact closure that causes the unit to begin unoccupied control. In this mode, the controller will use the Unoccupied Cooling and Heating setpoints to determine capacity control needs. Stand Alone Unoccupied control is only applicable when the unit is not being controlled by a conventional thermostat interface.

Timed Override

Exceptions to the time-of-day scheduling are required when unusual or difficult to schedule events cause a space to become occupied during a scheduled unoccupied period. The Timed Override function provides a mechanism for an occupant to signal the system that the space is actually occupied and override the time-of-day schedule to provide occupied control for some limited time period. It also provides a mechanism to return the system to unoccupied mode when the space is no longer occupied.

There are two methods of requesting or terminating timed override on a Symbio™ 700 control system:

- BAS
 - Timed Override Request value can be set to three discrete values:
 - **Idle [1]**— Controller will not override Unoccupied Mode.
 - **On [2]**— When the value is changed from Idle to On, the controller overrides Unoccupied Mode and the unit operates in Occupied Mode. The Occupied Bypass Timer and the Timed Override Timer is Active is set to 'Active'. The controller remains in Timed Override for the duration of the Occupied Bypass Time.
 - **Cancel [3]**— When value is changed from On to Cancel, the unit's unoccupied status is no longer overridden and the Occupied Bypass Timer will be set to 0.
- Zone Sensor Initiate/Terminate buttons – Some zone sensors have a Timed Override Initiate and Terminate buttons.

When Timed Override is initiated by any of the above methods, the controller starts a timer using the user selected Occupied Bypass Time to control the duration of the Timed Override event. The range for Occupied Bypass Time is 0 to 240 minutes with a default of 120 minutes.

When the unit is operating in Occupied Bypass mode, the Occupied Bypass Timer duration can be extended by initiating a Timed Override Request again. This extends the Occupied Bypass Timer duration by the value of the user selected Occupied Bypass Time.

When Timed Override is terminated by any of the above methods, the controller will exit Occupied Bypass and will again begin to use unoccupied control setpoints.

Supply Air Tempering

If the Supply Air Tempering function is configured and the Discharge Air Temperature local sensor is valid, the Space Temperature Control algorithm manages the Supply Air Tempering function to prevent excessively cold discharge air from being supplied from the unit. The sequence for VVZT systems are consistent with CVZT systems, utilizing single-speed, and full airflow operation.

Building Automation System Support Sequences

Supply Air Tempering is not applicable when a Conventional TStat is configured as the Space Controller.

The following requirements must be met to allow Supply Air Tempering on a Staged Heat unit:

- The supply fan is ON.
- The unit is in Occupied mode.
- The unit is in any heating mode, including Heat, Emergency Heat, Morning Warmup, Max Heat but is not actively heating OR
- The unit is in any cooling mode except night purge, but not actively cooling and cooling capacity has been OFF for 5 minutes.

If the discharge air temperature drops to the Discharge Air Temperature Minimum Cool Limit - Active and the Space Temperature is less than the Active Space Temp Cooling Setpoint Status – 0.5°F and if there are no stages of heat on, the Supply Air Tempering function will bring ON one stage of available staged auxiliary heat.

Note: Heat Pump units will energize 1 stage of auxiliary Heat in order to meet the Supply Air Tempering request; compressor-based heating will not be used to satisfy Supply Air Tempering.

Once Supply Air Tempering is active, the stage of heat will be turned OFF if the Discharge Air Temperature rises to 10°F ABOVE the Discharge Air Temperature Minimum Cool Limit - Active, or the Space Temperature rises to the Space Temp Cooling Setpoint Status. Additionally, if the Space Heat Control function determines that 1 or more stages of Heat are required to meet the Space Temp Heating Setpoint Status, Tempering will be discontinued and the unit will stage heating to meet the current space demand.

Unit Stop

The Unit Stop feature allows for immediate shutdown of all devices in the equipment when initiated. When a Unit Stop request is received, the following actions are taken:

- All equipment control binary outputs are de-energized.
 - Indoor fan
 - Compressors
 - Condenser fans
 - Unloader solenoids
 - Heat stages
- All equipment control analog outputs are set to their minimum/off command values.
- All communicating devices, such as Supply fan VFD, are commanded to their OFF state.
- All control algorithms are initialized to their normal startup values and held until the stop request is released.

The Unit Stop request can be initiated from the following sources:

- Unit Stop Command
- Equipment Shutdown Input
- Emergency Override BAS
- Phase Monitor

If a Unit Stop is initiated, the source of the Unit Stop can be determined by the Unit Stop Source Point and other status/diagnostic points.

Capacity Limit Control

The Symbio™ 700 provides the following capabilities to lockout or limit heat and cool capacity installed in the equipment (these capabilities interact):

- Capacity Lockout points have highest priority.
- When Heat Lockout Command and Cooling Lockout BAS are false (not locked out); the control will limit capacity based on Cooling Capacity Enable and Primary Heat Enable.

- Last in priority is Demand Limit Request BAS which enables independent limits on cooling and heating capacity.

See the following sections for more details of each.

Priority	Cooling Limits	Heating Limits
1	Cooling Lockout BAS	Heat Lockout Command
2	Cooling Capacity Enable	Primary Heat Enable BAS
3	<ul style="list-style-type: none"> • Demand Limit Request BAS • Demand Limit Input (binary input) • Cooling Demand Limit Capacity Enable Setpoint 	<ul style="list-style-type: none"> • Demand Limit Request BAS • Demand Limit Input (binary input) • Heating Demand Limit Capacity Enable Setpoint

Capacity Lockouts

Capacity Lockout points are available to the building automation to provide a method to override or lockout DX Cooling, Gas Heating and Electric Heating. Cooling Lockout BAS will disable all DX cooling capacity while economizer operation is allowed. Heat Lockout Command disables all forms of installed primary and secondary heating capacity.

Cooling Capacity Enable

Cooling Capacity Enable is a building automation interface point used to limit the DX cooling capacity of the equipment. It will not limit economizer cooling. The 0 to 100% value limits the amount of cooling capacity; default is 100%. The cooling stages allowed = (Limit % * number of stages), round down to the nearest integer.

Heat Primary Enable

Primary Heat Enable BAS is a building automation interface point used to limit all forms of primary and secondary heat installed in the equipment (gas, electric, compressor). The 0 to 100% value limits the amount of heating capacity, default is 100%. Staged heating stages allowed = (Heat Primary Enable * number of stages), round down to the nearest integer.

Examples:

- A stage heat pump unit with 2-stages of supplemental electric heat, the total stages of heat is 5. Electric heat is supplemental to compressor heating. Primary Heat Enable BAS will be applied to five stages of heat.
- A stage heat pump unit with 2-stages of gas heat, Primary Heat Enable BAS is applied to 3-stages of compressor heating when active or 2-stage of gas heat when it is active.

Demand Limit

When Demand Management is configured for Demand Limit, demand limits can be applied via building management points or the Demand Limit Input (Symbio 700 J16-1 and J16-2). The primary purpose of this function is to limit power consumption of heating and cooling capacities installed in the equipment. Demand Limit does not apply to economizer cooling nor hot gas reheat.

If no building management is writing to the Demand Limit Request BAS point, demand limit can be enabled or disabled by the Demand Limit Input (hardware binary input). Otherwise, if Demand Limit Request BAS is being commanded, it will have priority over the hardware binary input. The result of the arbitration between Demand Limit Request BAS and the Demand Limit Input is reported via Demand Limit Request BAS – Active point.

When Demand Limit Request BAS – Active point is Limit (true), Cooling Demand Limit Capacity Enable Setpoint (0 to 100%) and Heating Demand Limit Capacity Enable Setpoint (0 to 100%) apply limits to cooling and heating capacity, respectively. The power consumption result will depend on the allowed heating and cooling stages. Cooling Demand Limit Capacity Enable Setpoint limits compressor stages of operation however will not limit economizer cooling. Heating Demand Limit Capacity Enable Setpoint limits the stages of heat pump and electric heat; however, Heating Demand Limit Capacity Enable will not limit gas heat.

Building Automation System Support Sequences

Calculation: Number of heating or cooling stages allowed = (Limit % * number of stages), round down to the nearest integer.

Example: 3-stage Cooling Only unit with 2-stage primary heat

When Demand Limit Request BAS – Active is Limited and Heating Demand Limit Capacity Enable Setpoint is 60%, 2-stage primary heat installed, limits operation to 1-stage of heat. $(60\% * 2) = 1.2$, round down to nearest integer = 1.

When Demand Limit Request BAS – Active is Limited and Cooling Demand Limit Capacity Enable Setpoint is 90%, 3-stages cooling installed, limits operation to 2-stages of cooling. $(90\% * 3) = 2.7$, round down to nearest integer = 2.

Heat Pump Example: 2-stage Heat Pump unit with 2-stage electric heat

When Demand Limit Request BAS – Active is Limited and Heating Demand Limit Capacity Enable Setpoint is 80%, 2-stages of primary heat and 2-stages of supplemental heat are installed (total of 4 stages). Operation is limited to 2-stages of compressor heat and 1 stage of electric heat. $(80\% * 4) = 3.2$, round down to nearest integer = 3 stages of heat.

Heat Pump Example: 2-stage Heat Pump unit with 2-stage gas heat

When Demand Limit Request BAS – Active is Limited and Heating Demand Limit Capacity Enable Setpoint is 80%, 2-stages of primary heat or 2-stages of supplemental heat are installed (total of 2 stages). Demand Limit does not apply to gas heat so the limit will only apply to compressor heating. $(80\% * 2) = 1.6$, round down to nearest integer = 1 stage of heat.

Remote Capacity Control

The Symbio 700 controls support the Remote Capacity Control function, which allows a user to directly control the unit capacity rather than allowing the internal algorithm to provide control.

The following features/functions can be requested directly via points, rather than relying on internal temperature or thermostat control sequences:

- Supply Fan Speed
- Cooling Capacity
- Heating Capacity

For Thermostat Controlled equipment, the Thermostat Inputs must be "OPEN" i.e. requesting "OFF" mode before the Cooling or Heating Capacity requests will be honored.

For Space Temperature controlled equipment, the Heat Cool Mode Request must be set to "Fan Only" before the Cooling or Heating Capacity requests will be honored.

For each entity, there is an "Enable" point to enable or disable the remote capacity control, and an analog value point to allow the user to request an analog capacity value. The analog value is translated to the appropriate value per function.

Supply Fan Speed Command overrides will be honored in all non-Heat or Off modes. When Supply Fan Speed Command is enabled, and the Supply Fan Speed Command value is 0%, the system will interpret as an "OFF" mode request, and all active capacity will be set to "OFF"; fan, heating, and cooling.

All equipment safeties and limitations will be in-place while the Remote Capacity Control functions are being leveraged:

- Minimum fan speeds as defined per active capacity will be maintained.
- Compressor Minimum ON/OFF times will be maintained.
- All system diagnostics will be maintained.

Emergency and Ventilation Override

This feature has two options for initiating an override request, either through the optional (future) hardwired Ventilation Override terminals, or by initiating a request through the Emergency Override Command point, a priority scheme is required to ensure proper equipment operation.

Ventilation Override (Future)

When configured for the Ventilation Override option, applying 24 volts to one of the three Ventilation Override inputs manually activates Ventilation Override. Three inputs are provided to support Ventilation Override functionality:

- Pressurize mode
- Purge mode
- Exhaust mode

If more than one mode is requested at the same time, the Pressurize request will have priority followed by Purge, and then Exhaust. When Any Ventilation Override mode is active, all heating and cooling is turned off. For the case where the unit is required to turn OFF via hardwired interface, the Equipment Shutdown input is used.

Emergency Override

All units with Symbio 700 support the remote Emergency Override Command functionality. Within this point, there are addition enumerations versus the hardware Ventilation Override interface:

- 1 = EMERG_NORMAL
- 2 = EMERG_PRESSURIZE
- 3 = EMERG_DEPRESSURIZE
- 4 = EMERG_PURGE
- 5 = EMERG_SHUTDOWN
- 6 = EMERG_FIRE

Pressurize, Depressurize, and Purge map to their respective Ventilation Override Modes directly. Emerg_Shutdown and Emerg_Fire are unique to Emergency Override. Both of those are treated as a remote shutdown request for the equipment.

Equipment Operation

Emergency and Ventilation Override requests/actions will take priority over normal equipment timing events, such as compressor minimum ON/OFF/Inter-stage timers.

During an Emergency or Ventilation Override sequence, all temperature control algorithms are initialized to an inactive state until the Emergency or Ventilation Override request is cleared. For each override request, the unit will operate in a pre-determined state until override requests are cleared.

For detailed unit operation during Emergency or Ventilation Override, See [“Appendix A,” p. 48](#) section of this document.



Service Test Mode

Service Test Mode can be used to initiate certain operating modes of the equipment. See the following sections for more details associated with this feature.

Service Test Timeout

Service Test Timeout (Minute) is a user selected time value. Once Service Test Mode has been initiated, and this timer expires, the controls are forced to leave Service Test Mode and return to normal unit operation.

- **Minimum value** - 1 minute
- **Maximum value** - 120 minutes
- **Default value** - 60 minutes

Timer Initiate: When any value for Service Test State Request is chosen other than Inactive, the controller sets the Service Test Timeout to the user selected value and the unit begins to operate as described in the tables below. It continues in operation until the Service Test Timeout Timer reaches 0 **OR** until the user chooses a different Service Test State Request.

Timer Terminate: if the Service Test Timeout timer has reached 0, the controls sets the Service Test Stage Request to Inactive and the unit returns to normal unit operation. If the Service Test Timeout Timer has not reached 0, the user can set the Service Test Stage Request to Inactive to exit the active Service Test State Request and return to normal unit operation.

Timer Reset: if the Service Test Timeout timer has not reached 0, the user can select the Service Test Stage Request to any value other than Inactive. The controller resets the Service Test Timeout Timer to the user selected value and the unit operates as describe in the tables below for the new request.

Leaving Service Test Mode

There are three ways to leave Service Test Mode:

- When the Service Test Timeout timer expires, the unit will leave Service Test Mode.
- Service Test State Request is set to **Inactive**.
- The controller goes through a power cycle or reset.

Constant Volume Supply Fan Service Test Mode

The tables below provide unit operation for each stage of service test depending on the unit configuration.

The tables describe the service test mode states and expected unit response. For all service test mode operation, "IN CONTROL" refers to Symbio 700 control algorithms controlling the unit. For instance, in all service test mode states, the Condenser Fan will be controlled as needed to ensure safe unit operation.

Table 13. Cooling only

State #	Service Test State Request	Service Test Supply Fan On/Off Request ^(a)	Service Test Compressor Cool Stage Request ^(b)	Service Test Auxiliary Heat Stage Request ^(c)	Service Test Condenser Fan Stage Request ^(d)	Heat Cool Mode Status
1	Inactive	IN CONTROL	IN CONTROL	IN CONTROL	IN CONTROL	IN CONTROL
2	Fan On	ON	0	0	IN CONTROL	TEST
3	Cool 1	ON	1	0	IN CONTROL	TEST
4	Cool 2	ON	2	0	IN CONTROL	TEST
5	Heat 1	ON	0	1	IN CONTROL	TEST
6	Heat 2	ON	0	2	IN CONTROL	TEST
7	Heat 3	ON	0	3	IN CONTROL	TEST

Table 13. Cooling only (continued)

State #	Service Test State Request	Service Test Supply Fan On/Off Request ^(a)	Service Test Compressor Cool Stage Request ^(b)	Service Test Auxiliary Heat Stage Request ^(c)	Service Test Condenser Fan Stage Request ^(d)	Heat Cool Mode Status
8	Heat 4	ON	0	4	IN CONTROL	TEST
9	Defrost	OFF	0	0	IN CONTROL	TEST
10	Emergency Heat	ON	0	2	IN CONTROL	TEST

^(a) Supply fan speed will operate the same as in normal cooling/heating operations. The minimum speeds can be found in the Appendix of this document.

^(b) Compressor cool stages are defined within the Appendix of this document.

^(c) Available auxiliary heat stages are defined within the Appendix of this document.

^(d) Condenser Fan stages are defined within the Appendix of this document.

Table 14. Heat pump

State #	Service Test State Request	Service Test Supply Fan On/Off Request ^(a)	Service Test Compressor Cool Stage Request ^(b)	Service Test Compressor Heat Stage Request ^(c)	Service Test Auxiliary Heat Stage Request ^(d)	Service Test Condenser Fan Stage Request ^(e)	Heat Cool Mode Status
1	Inactive	IN CONTROL	IN CONTROL	IN CONTROL	IN CONTROL	IN CONTROL	IN CONTROL
2	Fan On	ON	0	0	0	IN CONTROL	TEST
3	Cool 1	ON	1	0	0	IN CONTROL	TEST
4	Cool 2	ON	2	0	0	IN CONTROL	TEST
5	Heat 1	ON	0	1	0	IN CONTROL	TEST
6	Heat 2	ON	0	2	0	IN CONTROL	TEST
7	Heat 3	ON	0	3	1	IN CONTROL	TEST
8	Heat 4	ON	0	4	2	IN CONTROL	TEST
9	Defrost ^(f)	ON	0	2	1	IN CONTROL	TEST
10	Emergency Heat	ON	0	0	2	IN CONTROL	TEST

Note: Reversing Valve operation can be found in the Reversing Valve section of this document.

^(a) Supply fan speed will operate the same as in normal cooling/heating operations. The minimum speeds can be found in the Appendix of this document.

^(b) Compressor cool stages are defined within the Appendix of this document.

^(c) Compressor heat stages are defined within the Appendix of this document.

^(d) Available auxiliary heat stages are defined within the Appendix of this document.

^(e) Condenser Fan stages are defined within the Appendix of this document.

^(f) During Defrost, the unit will run Defrost operation until defrost terminate point is reached. After active defrost is terminated, the unit will run in active Heat mode but will return to Defrost if it is determined to be needed by the controls.

Multi-Speed Supply Fan Service Test Mode

Table 15. Cooling only

State #	Service Test State Request	Service Test Supply Fan On/Off Request	Service Test Supply Fan Speed Request ^(a)	Service Test Compressor Cool Stage Request ^(b)	Service Test Auxiliary Heat Stage Request ^(c)	Service Test Condenser Fan Stage Request ^(d)	Heat Cool Mode Status
1	Inactive	IN CONTROL	IN CONTROL	IN CONTROL	IN CONTROL	IN CONTROL	IN CONTROL
2	Fan On	ON	IN CONTROL	0	0	IN CONTROL	TEST
3	Cool 1	ON	IN CONTROL	1	0	IN CONTROL	TEST
4	Cool 2	ON	IN CONTROL	2	0	IN CONTROL	TEST
5	Heat 1	ON	IN CONTROL	0	1	IN CONTROL	TEST
6	Heat 2	ON	IN CONTROL	0	2	IN CONTROL	TEST
7	Heat 3	ON	IN CONTROL	0	3	IN CONTROL	TEST
8	Heat 4	ON	IN CONTROL	0	4	IN CONTROL	TEST



Service Test Mode

Table 15. Cooling only (continued)

State #	Service Test State Request	Service Test Supply Fan On/Off Request	Service Test Supply Fan Speed Request (a)	Service Test Compressor Cool Stage Request (b)	Service Test Auxiliary Heat Stage Request (c)	Service Test Condenser Fan Stage Request (d)	Heat Cool Mode Status
9	Defrost	OFF	IN CONTROL	0	0	IN CONTROL	TEST
10	Emergency Heat	ON	IN CONTROL	0	2	IN CONTROL	TEST

(a) Supply fan speed will operate the same as in normal cooling/heating operations. The minimum speeds can be found in the Appendix of this document.

(b) Compressor cool stages are defined within the Appendix of this document.

(c) Available auxiliary heat stages are defined within the Appendix of this document.

(d) Condenser Fan stages are defined within the Appendix of this document.

Table 16. Heat pump

State #	Service Test State Request	Service Test Supply Fan On/Off Request	Service Test Supply Fan Speed Request (a)	Service Test Compressor Cool Stage Request (b)	Service Test Compressor Heat Stage Request (c)	Service Test Auxiliary Heat Stage Request (d)	Service Test Condenser Fan Stage Request (e)	Heat Cool Mode Status
1	Inactive	IN CONTROL	IN CONTROL	IN CONTROL	IN CONTROL	IN CONTROL	IN CONTROL	IN CONTROL
2	Fan On	ON	IN CONTROL	0	0	0	IN CONTROL	TEST
3	Cool 1	ON	IN CONTROL	1	0	0	IN CONTROL	TEST
4	Cool 2	ON	IN CONTROL	2	0	0	IN CONTROL	TEST
5	Heat 1	ON	IN CONTROL	0	1	0	IN CONTROL	TEST
6	Heat 2	ON	IN CONTROL	0	2	0	IN CONTROL	TEST
7	Heat 3	ON	IN CONTROL	0	2	1	IN CONTROL	TEST
8	Heat 4	ON	IN CONTROL	0	2	2	IN CONTROL	TEST
9	Defrost ^(f)	ON	IN CONTROL	2	0	1	IN CONTROL	TEST
10	Emergency Heat	ON	IN CONTROL	0	0	2	IN CONTROL	TEST

Note: Reversing Valve operation can be found in the Reversing Valve section of this document.

(a) Supply fan speed will operate the same as in normal cooling/heating operations. The minimum speeds can be found in the Appendix of this document.

(b) Compressor cool stages are defined within the Appendix of this document.

(c) Compressor heat stages are defined within the Appendix of this document.

(d) Available auxiliary heat stages are defined within the Appendix of this document.

(e) Condenser Fan stages are defined within the Appendix of this document.

(f) During Defrost, the unit will run Defrost operation until defrost terminate point is reached. After active defrost is terminated, the unit will run in active Heat mode but will return to Defrost if it is determined to be needed by the controls.

Variable Speed Supply Fan Service Test Mode

Table 17. Cooling only

State #	Service Test State Request	Service Test Supply Fan On/Off Request	Service Test Supply Fan Speed Request (a)	Service Test Compressor Cool Stage Request (b)	Service Test Auxiliary Heat Stage Request (c)	Service Test Condenser Fan Stage Request (d)	Heat Cool Mode Status
1	Inactive	IN CONTROL	IN CONTROL	IN CONTROL	IN CONTROL	IN CONTROL	IN CONTROL
2	Fan On	ON	IN CONTROL	0	0	IN CONTROL	TEST
3	Cool 1	ON	IN CONTROL	1	0	IN CONTROL	TEST
4	Cool 2	ON	IN CONTROL	2	0	IN CONTROL	TEST
5	Heat 1	ON	IN CONTROL	0	1	IN CONTROL	TEST
6	Heat 2	ON	IN CONTROL	0	2	IN CONTROL	TEST
7	Heat 3	ON	IN CONTROL	0	3	IN CONTROL	TEST
8	Heat 4	ON	IN CONTROL	0	4	IN CONTROL	TEST

Table 17. Cooling only (continued)

State #	Service Test State Request	Service Test Supply Fan On/Off Request	Service Test Supply Fan Speed Request (a)	Service Test Compressor Cool Stage Request (b)	Service Test Auxiliary Heat Stage Request (c)	Service Test Condenser Fan Stage Request (d)	Heat Cool Mode Status
9	Defrost	OFF	IN CONTROL	0	0	IN CONTROL	TEST
10	Emergency Heat	ON	IN CONTROL	0	2	IN CONTROL	TEST

(a) Supply fan speed will operate the same as in normal cooling/heating operations. The minimum speeds can be found in the Appendix of this document.

(b) Compressor cool stages are defined within the Appendix of this document.

(c) Available auxiliary heat stages are defined within the Appendix of this document.

(d) Condenser Fan stages are defined within the Appendix of this document.

Table 18. Heat pump

State #	Service Test State Request	Service Test Supply Fan On/Off Request	Service Test Supply Fan Speed Request (a)	Service Test Compressor Cool Stage Request (b)	Service Test Compressor Heat Stage Request (c)	Service Test Auxiliary Heat Stage Request (d)	Service Test Condenser Fan Stage Request (e)	Heat Cool Mode Status
1	Inactive	IN CONTROL	IN CONTROL	IN CONTROL	IN CONTROL	IN CONTROL	IN CONTROL	IN CONTROL
2	Fan On	ON	IN CONTROL	0	0	0	IN CONTROL	TEST
3	Cool 1	ON	IN CONTROL	1	0	0	IN CONTROL	TEST
4	Cool 2	ON	IN CONTROL	2	0	0	IN CONTROL	TEST
5	Heat 1	ON	IN CONTROL	0	1	1	IN CONTROL	TEST
6	Heat 2	ON	IN CONTROL	0	2	2	IN CONTROL	TEST
7	Heat 3	ON	IN CONTROL	0	2	3	IN CONTROL	TEST
8	Heat 4	ON	IN CONTROL	0	2	4	IN CONTROL	TEST
9	Defrost ^(f)	OFF	IN CONTROL	0	0	0	IN CONTROL	TEST
10	Emergency Heat	ON	IN CONTROL	0	0	2	IN CONTROL	TEST

Note: Reversing Valve operation can be found in the Reversing Valve section of this document.

(a) Supply fan speed will operate the same as in normal cooling/heating operations. The minimum speeds can be found in the Appendix of this document.

(b) Compressor cool stages are defined within the Appendix of this document.

(c) Compressor heat stages are defined within the Appendix of this document.

(d) Available auxiliary heat stages are defined within the Appendix of this document.

(e) Condenser Fan stages are defined within the Appendix of this document.

(f) During Defrost, the unit will run Defrost operation until defrost terminate point is reached. After active defrost is terminated, the unit will run in active Heat mode but will return to Defrost if it is determined to be needed by the controls.



Diagnostics

Device Tracker

Symbio 700 will keep statistical data of the unit for component starts and component run times (in hours) for the following unit components:

- Compressor 1
- Compressor 2
- Condenser Fan 1
- Condenser Fan 2
- Supply Fan
- Electric Heat Stage 1
- Electric Heat Stage 2
- Filter (Runtime only)

If the Filter Runtime hours exceed the value set by the user for the Filter Runtime Hours Setpoint, the Symbio 700 controller activates the Diagnostic: Maintenance Required point.

If for any reason it is required to reset the component statistical data, the Run Time Reset or Starts Reset points can be accessed through the Symbio Service and Installation mobile app.. If the reset points are set to Reset, the Component Run Time and Starts are reset to 0 and the associated reset points are set back to inactive. In the case of the Diagnostic: Maintenance Required point, it will also be reset to Inactive if Filter Timer Reset point is set.

Compressor Proving Diagnostics

Three diagnostics can be generated based on the compressor proving input.

Diagnostic: Compressor X Proving Trip

When a compressor output is commanded ON and it has been running for more than 5 seconds, if the associated proving input opens, the controls generate the Diagnostic: Comp X Proving Trip and the following will occur:

- Command the associated compressor output OFF immediately.
- Command any compressor output OFF that is on the same refrigeration circuit as the compressor which had the proving input trip.
- The Circuit is disabled for 15 minutes.

After the 15 minute compressor proving timeout has expired, if the unit is not under a “Diagnostic: Compressor 1 Proving Lockout” event

- The Diagnostic: Comp X Proving Trip diagnostic is reset
- If the cooling stage is still requested ON, the circuit is allowed to stage again

Diagnostic: Compressor X Proving Lockout

There are two cases that can cause a Diagnostic: Compressor X Proving Lockout:

- If a refrigeration circuit accumulates 4 consecutive Diagnostic: Comp X Proving Trips during the same compressor operating cycle, a Diagnostic: Compressor X Proving Lockout is generated.

Note: If the call for the compressor operation terminates, the counter is set to zero.

- If a compressor associated proving input does not CLOSE within 5 seconds of the compressor startup.

If a Diagnostic: Compressor X Proving Lockout is generated the following will occur:

- All compressors on the associated circuit are de-energized immediately and they are locked out until a Reset Diagnostic action is initiated.
- The “Diagnostic: Compressor X Proving Lockout” diagnostic point is activated and the alarm output is activated.

Diagnostic: Compressor X Contactor Failure

If a compressor proving input becomes Active for 5 continuous seconds when the associated compressor command output is Inactive, a Diagnostic: Compressor X Contactor Failure is generated and the following occurs:

- All compressors on the associated circuit are de-energized immediately and they are locked out until a Reset Diagnostic is initiated.

The “Compressor X Contactor Failure” diagnostic point is activated and the alarm output is activated.

Diagnostics – Low Pressure Cutout

The following operation is enforced based on the state of the circuit's LPC input:

Prior to Compressor Startup:

- If a compressor output is Off and its circuit's LPC input is open, compressor operation is not inhibited, and the **Diagnostic: Circuit X LPC Trip** point will not be annunciated.

After Compressor Startup:

An LPC Bypass Delay function delays the setting of a low pressure cutout after compressor startup on a circuit until a pre-determined amount of time passes in low ambient conditions. The length of the delay is determined based on ambient temperature:

- If the Outdoor Air Temperature Active is less than 40° F, the LPC Bypass Delay is set to 60 seconds.
- If the Outdoor Air Temperature Active is between 40° F and 50° F, the LPC Bypass Delay is set to 30 seconds.
- If the Outdoor Air Temperature Active is greater than 50° F, the LPC Bypass Delay is 0 seconds.

There are two diagnostics that can be generated based on the Compressor Low Pressure Cutout input:

Diagnostic: Circuit X LPC Trip

- All compressors outputs on the effected circuit are commanded OFF.
- The Diagnostic: Circuit X LPC Trip point is annunciated.
- The circuit is disabled for 3 minutes.
- The circuit LPC trip counter is incremented.

After the 3 minute low pressure event timeout has expired, if the unit is not under a lockout event:

- The Diagnostic: Circuit X LPC Trip point is reset.
- If the stage is still requested ON, the circuit is allowed to stage again.
- If the Circuit runs for 3 minutes, its LPC Trip Count is reset to 0.

On heat pumps, if the Outdoor Air Temperature is less than 0° F or if the unit is in active defrost, the low pressure cutout input state is ignored.

Diagnostic: Circuit X LPC Lockout

If a circuit LPC trip counter accumulates 4 low pressure events without the circuit running for the 3 minute minimum on time (counter is not reset), a Diagnostic: Circuit X LPC Lockout is generated.

Once a Diagnostic: Circuit X LPC Lockout has been generated, the following occurs:

- All compressors on the associated circuit are de-energized immediately and they are locked out until a Reset Diagnostic is initiated.
- The Diagnostic: Circuit X LPC Lockout point is activated and the alarm output is activated.

Diagnostics – Alarm Indicator Status

Symbio™ 700 will support an Alarm Indicator Status point that if configured, drives the state of a relay output on the Customer Connection Module. This point is set to active when a failure occurs that functionally stops a critical component within the HVAC system.

For a list of all supported Symbio 700 Diagnostics and if it sets the Alarm Indicator, See “Appendix A,” p. 48 section of this document.



Reset Diagnostic

A Reset Diagnostic function is responsible for ensuring that the Reset Diagnostic point is set to the right value under normal application control. The below sections describes how the Reset Diagnostic point is set to Active and Inactive.

Power-Up Reset or Exception/Override Mode Transition

At power-up or after the unit leaves an Exception or Override mode, all diagnostics are cleared, and the application starts over.

Reset Diagnostic Point

Diagnostic Resets throughout the controller application are triggered by the state of the Reset Diagnostic Point. The Reset Diagnostic point is setup as a last-write-wins point type, so it can be controlled by the local UI on the Symbio™ 700 or can be communicated.

Heat Cool Mode Transition Reset

When the unit is controlled by a zone sensor, a transition from System Mode Switch Local = OFF to System Mode Switch Local \neq OFF triggers a Reset Diagnostic request.

Reset Diagnostic Point – Active to Inactive Transition

When the diagnostic reset function detects the state of the Reset Diagnostic point is Active, after 5 seconds, the Diagnostic Reset function sets the Reset Diagnostic point to Inactive.



Troubleshooting

The Symbio™ 700 controller provides system shutdown, operational default operation, and communication error handling of the Odyssey unit. The list of fault conditions below will stop normal operation or change the operation of the unit to a default condition. Faults are indicated in the Active Alarm menu of the onboard user interface and the Symbio Service and Installation mobile app.

Unit Communication Fault

The maximum time for the inter-module communications (IMC) bus is 15 seconds. If 15 seconds passes with no valid communications received from any of the Options modules, the Symbio 700 takes the following actions:

Module	Symbio 700 Response	Response Type
Symbio 700 Onboard I/O	<ul style="list-style-type: none">Set Diagnostic: Unit Communications FailureOn-Board I/O Communication Status = Not CommunicatingAll unit functions will be shut down and I/O will go to their comm. loss state	Auto Reset
Customer Options Module	<ul style="list-style-type: none">Set Diagnostic: Unit Communications FailureCustomer Options Module Communication Status = Not CommunicatingAll unit functions that have dependencies on data from other modules will be discontinued<ul style="list-style-type: none">Ventilation Override functionality is discontinuedAlarm Indicator function is discontinued	Auto Reset
Indoor Options Module	<ul style="list-style-type: none">Set Diagnostic: Unit Communications FailureIndoor Options Module Communication Status = Not CommunicatingAll unit functions that have dependencies on data from other modules will be discontinued<ul style="list-style-type: none">All Electric Heat operation is discontinuedDischarge Air Temperature dependent control discontinued (SZVAV)	Auto Reset

Sensor Fault

On Symbio 700, if a sensor value goes outside of its minimum or maximum range, the point goes into an Alarm State. If the point in the Alarm State, we consider the sensor failed and take the following actions:

Fault	Symbio 700 Response	Response Type
Space Temperature Active	<ul style="list-style-type: none">Annunciated in the Active Alarm list.For specific unit operational response, see "Space Temperature Control Sequence of Operation," p. 17.	Auto Reset
Discharge Air Temperature Local	<ul style="list-style-type: none">Annunciated in the Active Alarm list.For specific unit operational response, see "Space Temperature Control Sequence of Operation," p. 17.	Auto Reset
Outdoor Air Temperature Active	<ul style="list-style-type: none">Annunciated in the Active Alarm list.Heat Pump Low Ambient functionality is disabled.	Auto Reset

Fault	Symbio 700 Response	Response Type
Coil Temperature Sensor 1	<ul style="list-style-type: none"> Annunciated in the Active Alarm list. If Outdoor Air Temperature < 52° F, Demand Defrost will be disabled and timed defrost will be used. 	Auto Reset
Coil Temperature Sensor 2	<ul style="list-style-type: none"> Annunciated in the Active Alarm list. If Outdoor Air Temperature < 52°F, Demand Defrost will be disabled and timed defrost will be used. 	Auto Reset
Space Humidity Sensor	Annunciated in the Active Alarm list.	Auto Reset
Space CO ₂ Sensor	Annunciated in the Active Alarm list.	Auto Reset

Compressor Fault

Symbio 700 supports compressor safety functionality to keep the compressors from operating in an undesirable condition. If a compressor safety failure occurs, the following actions occur:

Fault	Symbio 700 Response	Response Type
LPC Lockout	For specific operation associated with the LPC diagnostics, refer to the Compressor Protection section of this document.	Manual Reset
Proving Lockout	For specific operation associated with the proving diagnostics, refer to the Compressor Protection section of this document.	Manual Reset
Contactor Failure	For specific operation associated with the proving diagnostics, refer to the Compressor Protection section of this document.	Manual Reset

VFD Fault

The following failures are derived either through direct data monitoring from the Modbus device, or through a combination of Modbus data and additional failure criteria:

Fault	Fault Detection	Symbio 700 Response	Response Type
Diagnostic: Supply Fan Failure	If while the Supply Fan VFD is requested to run, the VFD Running Status from the drive is set to False for 40 continuous seconds, this failure will be detected	<ul style="list-style-type: none"> Diagnostic: Supply Fan Failure will be set to Active All unit functions will be shut down immediately 	Manual Reset
Diagnostic: VFD Fault Supply Fan – 1	When Active	All unit functions will be shut down immediately	Auto Reset
Diagnostic: VFD Supply Fan Ground Fault – 1	When Active	All unit functions will be shut down immediately	Auto Reset
Diagnostic: VFD Supply Fan Motor Current Overload – 1	When Active	All unit functions will be shut down immediately	Auto Reset
Diagnostic: VFD Supply Fan Short Circuit – 1	When Active	All unit functions will be shut down immediately	Auto Reset
Supply Fan VFD Communication Status	If continual loss of communication between the controller and the VFD has occurred for a 30-second period, this failure will be detected.	<ul style="list-style-type: none"> Supply Fan VFD Communication Status will be set to Not Communicating All unit functions will be shut down 	Manual Reset

Defrost Fault

The below list of diagnostics are associated with the Demand Defrost Function.

Fault	Fault Detection	Symbio 700 Response	Response Type
Diagnostic: Demand Defrost Disabled	<ul style="list-style-type: none"> Set Diagnostic: Demand Defrost Disabled with any Demand Defrost Fault on non-independent circuit heat pumps.- Set Diagnostic Demand Defrost Disable Ckt X with any Demand Defrost Fault on any circuit for independent condenser systems. 	<ul style="list-style-type: none"> Set Diagnostic: Demand Defrost Disabled For Independent Circuit Heat Pump units, set Diagnostic Demand Defrost Disable Ckt X (depending on the associated circuit) Revert to Default Defrost operation. See Demand Defrost Faults below 	Manual Reset
Diagnostic: Demand Defrost Disabled Ckt 1			
Diagnostic: Demand Defrost Disabled Ckt 2			
Diagnostic: Demand Defrost Fault A		<ul style="list-style-type: none"> Initiate Defrost If Low $\Delta T > 2$ hours: <ul style="list-style-type: none"> Set Diagnostic: Demand Defrost Disabled Set Diagnostic: Default Defrost Fault A For Independent Circuit Heat Pump units, set Diagnostic: Demand Defrost Disable Ckt X Set Diagnostic: Default Defrost Fault A Ckt X Initiate Defrost Reset timer if ΔT returns within bounds 	Manual Reset
Diagnostic: Demand Defrost Fault A Ckt 1			
Diagnostic: Demand Defrost Fault A Ckt 2	ΔT is below minimum value 12 minutes after defrost is terminated.		
Diagnostic: Demand Defrost Fault B		<p>If defrost is terminated on time requirement (vs differential temp)</p> <ul style="list-style-type: none"> Set Diagnostic: Default Defrost Fault B For Independent Circuit Heat Pump units, set Diagnostic: Default Defrost Fault B Ckt X Increment Demand Defrost Fault B counter After counter = 10 Set Diagnostic: Demand Defrost Disabled or for Independent Circuit unit For Independent Circuit Heat Pump units, set Diagnostic: Demand Defrost Disable Ckt X 	Manual Reset
Diagnostic: Demand Defrost Fault B Ckt 1			
Diagnostic: Demand Defrost Fault B Ckt 2	Defrost terminated on time requirement		
Diagnostic: Demand Defrost Fault C		<ul style="list-style-type: none"> Set Diagnostic: Default Defrost Fault C or for Independent Circuit units, set Diagnostic: Default Defrost Fault C Ckt X Initiate Defrost Increment Demand Defrost Fault C counter After counter = 16 Set Diagnostic: Demand Defrost Disabled or for Independent Circuit units Set Diagnostic: Demand Defrost Disable Ckt X 	Manual Reset
Diagnostic: Demand Defrost Fault C Ckt 1			
Diagnostic: Demand Defrost Fault C Ckt 2	ΔT is above Maximum Value 12 minutes after defrost is terminated		
Diagnostic: Demand Defrost Fault D	ΔT does not change by 2°F in 1 hour, starting 12 minutes after defrost is terminated and ΔT is less than or equal to 6 but greater than Low ΔT degrees 12 minutes after defrost is terminated.	<ul style="list-style-type: none"> Initiate Defrost Set Diagnostic: Demand Defrost Disabled Set Diagnostic: Default Defrost Fault D 	Manual Reset



Appendix A

Supply Fan

Multi-Speed/VFD

Table 19. Multi-speed minimum supply fan speeds

Unit Operation	Supply Fan Speed
Off	0%
Fan Only	41.7%
Cooling Stage 1	41.7%
Cooling Stage 2	100%
Heat Pump Heating	100%
Electric/Auxiliary Heating	100%

Variable Speed/VFD

Table 20. Variable speed minimum supply fan speeds

Unit Operation	Supply Fan Speed
Off	0%
Fan Only	58%
Cooling Stage 1	58%
Cooling Stage 2	80%
Heat Pump Heating	100%
Electric/Auxiliary Heating	100%

Compressor Staging

Thermostat Staging

For equipment staging response to a conventional thermostat signals, See [“Conventional Thermostat Sequence of Operation,” p. 15.](#)

Cooling Only (Electric Heat) – CVZT and VVZT

Table 21. Single compressor cooling staging

Unit Operation	Unit Response
Cooling Stage 1	Compressor 1 Output ON

Table 22. Dual compressor cooling staging (manifold or independent)

Unit Operation	Unit Response
Cooling Stage 1	Compressor 1 Output ON
Cooling Stage 2	Compressor 1 Output ON + Compressor 2 Output ON

Table 23. Dual unloading compressor cooling staging

Unit Operation	Unit Response
Cooling Stage 1	Compressor 1 Output ON + Compressor 2 Output ON
Cooling Stage 2	Compressor 1 Output ON + Compressor 1 Unloader Solenoid ON + Compressor 2 Output ON + Compressor 2 Unloader Solenoid ON

Heat Pump – CVZT and VVZT

Table 24. Single compressor cooling staging

Unit Operation	Unit Response
Cooling Stage 1	Compressor 1 Output ON

Table 25. Dual compressor cooling staging (manifold or independent)

Unit Operation	Unit Response
Cooling Stage 1	Compressor 1 Output ON
Cooling Stage 2	Compressor 1 Output ON + Compressor 2 Output ON

Condenser Fan Operation

Thermostat, CVZT, and VVZT

Table 26. Single condenser fan systems (cooling only and heat pump)

Unit Operation	Unit Response
Compressor 1 Output ON	Condenser Fan Output 1 ON
Compressor 2 Output ON	Condenser Fan Output 1 ON
Compressor 1 Output ON + Compressor 2 Output ON	Condenser Fan Output 1 ON

Note: If Defrost is active on Heat Pump units, then Condenser Fan Output 1 OFF.

Table 27. Dual condenser fan - shared airstream (cooling only)

Unit Operation	Unit Response
Compressor 1 Output ON	Condenser Fan Output 1 ON + Condenser Fan Output 2 ON
Compressor 2 Output ON	Condenser Fan Output 1 ON + Condenser Fan Output 2 ON
Compressor 1 Output ON + Compressor 2 Output ON	Condenser Fan Output 1 ON + Condenser Fan Output 2 ON

Table 28. Dual condenser fan - independent airstream (cooling only and heat pump)

Unit Operation	Unit Response
Compressor 1 Output ON	Condenser Fan Output 1 ON
Compressor 2 Output ON	Condenser Fan Output 2 ON
Compressor 1 Output ON + Compressor 2 Output ON	Condenser Fan Output 1 ON + Condenser Fan Output 2 ON

Notes:

- If Defrost is active on Heat Pump refrigeration circuit 1, then unit response is Condenser Fan Output 1 OFF.
- If Defrost is active on Heat Pump refrigeration circuit 2, then unit response is Condenser Fan Output 2 OFF.

Electric Heat

CVZT and VVZT

Table 29. Electric heat staging

Unit Operation	Unit Response
Electric Heat Stage 1	Electric Heat Stage 1 Output ON
Electric Heat Stage 2	Electric Heat Stage 1 and 2 Outputs ON

Diagnostics and Alarm Indicator Status

Table 30. Odyssey supported diagnostics and alarm relay functionality

Diagnostic/Alarm	Alarm Indicator
Communication	
Diagnostic: Unit Communications Failure	Y
On-Board I/O Communication Status	Y
Customer Options Module Communication Status	Y
Indoor Options Module Communication Status	Y
Heat Options Module Communication Status	Y
Fresh Air Options Module Communication Status	Y
Supply Fan VFD Communication Status	Y
Supply Fan 1 Communication Status	Y
Refrigerant Leak Sensor Communication Status Sensor A	Y
VFD Supply Fan	
Diagnostic: Supply Fan Failure	Y
Diagnostic: Supply Fan Proving Failure	Y
Diagnostic: VFD Fault Supply Fan - 1	Y
Diagnostic: VFD Supply Fan Ground Fault - 1	Y
Diagnostic: VFD Supply Fan Motor Current Overload - 1	Y
Diagnostic: VFD Supply Fan Short Circuit - 1	Y
Diagnostic: VFD Supply Fan Broken Belt - 1	Y
Compressor	
Diagnostic: FroStat Trip	N
Diagnostic: Comp 1 Proving Trip	N
Diagnostic: Comp 2 Proving Trip	N
Diagnostic: Circuit 1 LPC Trip	N
Diagnostic: Compressor 1 Contactor Failure	Y

Table 30. Odyssey supported diagnostics and alarm relay functionality (continued)

Diagnostic/Alarm	Alarm Indicator
Diagnostic: Circuit 1 LPC Lockout	Y
Diagnostic: Compressor 1 Proving Lockout	Y
Diagnostic: Compressor 2 Contactor Failure	Y
Diagnostic: Circuit 2 LPC Lockout	Y
Diagnostic: Compressor 2 Proving Lockout	Y
Outdoor Air Damper	
FDD: Excessive Outdoor Air	Y
FDD: Outdoor Air Damper Not Modulating	Y
FDD: Unit Economizing When It Should Not	Y
FDD: Unit Not Economizing When It Should	Y
Refrigerant Detection System	
Diagnostic: Refrigerant Concentration Sensor A	Y
Diagnostic: Refrigerant Leak Sensor Failure Sensor A	Y
Refrigerant Leak Sensor Communication Status Sensor A	Y
Sensor and other	
Diagnostic: Maintenance Required	N
Diagnostic: Filter Change Required	N
Diagnostic: High Condensate Level Detected	N
Diagnostic: Condensate Overflow Lockout	Y
Diagnostic: Morning Warmup Mode Exceeded 120 Minutes	N
Diagnostic: Pre Cool Mode Exceeded 120 Minutes	N
Diagnostic: Night Purge Mode Exceeded 120 Minutes	N
Diagnostic: Supply Fan Bypass Enable	N
Discharge Air Temperature Local	Y
Outdoor Air Temperature Active	Y
Outdoor Air Humidity Active	Y
Phase Monitor Status	Y
Space CO ₂ Concentration Active	N
Space Humidity Active	N

Emergency and Ventilation Override

Table 31. Emergency and ventilation override

Inputs	Outputs					
Emergency Override BAS	EOM Supply Fan On/Off Request	EOM Supply Fan Speed Request	EOM Compressor Cool Stage Request	EOM Compressor Heat Stage Request	EOM Auxiliary Heat Stage Request	Heat Cool Mode Status
Point	State	%	Value	Value	Value	Point
2 = EMERG_PRESSURIZE	ON	100	0	0	0	Fan Only
3 = EMERG_DEPRESSURIZE	OFF	0	0	0	0	Fan Only
4 = EMERG_PURGE	ON	100	0	0	0	Fan Only
5 = EMERG_SHUTDOWN	OFF	0	0	0	0	OFF
6 = EMERG_FIRE	OFF	0	0	0	0	OFF
1 = EMERG_NORMAL	Auto	Auto	Auto	Auto	Auto	Auto

Internal and External Space Setpoint Adjustment

Zone sensors with an internal or external setpoint adjustment provide the controller with a local setpoint (50° F to 85° F or 10° C to 29.4° C). The internal setpoint adjustment is concealed under the zone sensor cover. To access the setpoint adjustment, remove the zone sensor cover. Some external setpoints (when present) are displayed on the digital display zone sensor front cover. When the local setpoint adjustment is used to determine the setpoints, all unit setpoints are calculated based on the local setpoint value, the configured setpoints, and the active mode of the controller. The controller determines the effective space setpoint based on the following:

- Local setpoint input (SET)
- The local setpoint calibration (configured)
- Whether or not the local setpoint adjustment can be used or not (configured)
- Communicated setpoint input
- Default setpoints (configured)
- Occupancy mode
- Heating or cooling mode (space demand)
- Space setpoint high and low limits (configured)

Heat mode:

- Occupied mode: Space Temperature Setpoint Active = Space Temperature Setpoint (arbitrated) - Occupied Offset
- Occupied standby mode: Space Temperature Setpoint Active = Space Temperature Setpoint (arbitrated) - Standby Offset
- Unoccupied mode: Space Temperature Setpoint Active = Unoccupied Heating Setpoint Cool mode

Cool mode:

- Occupied mode: Space Temperature Setpoint Active = Space Temperature Setpoint (arbitrated) + Occupied Offset
- Occupied standby mode: Space Temperature Setpoint Active = Space Temperature Setpoint (arbitrated) + Standby Offset
- Unoccupied mode: Space Temperature Setpoint Active = Unoccupied Cooling setpoint

When a building automation system or other controller communicates a setpoint to the controller, the controller ignores the local setpoint input and uses the communicated value. The exception is when the system is in unoccupied mode and the controller always uses the unoccupied setpoints. After the

controller completes all setpoint calculations, the calculated occupied setpoint is validated against the following configured space setpoint limits:

- Heating setpoint high limit
- Heating setpoint low limit
- Cooling setpoint high limit
- Cooling setpoint low limit

These setpoint limits apply only to the occupied and occupied standby, heating, and cooling setpoints. They do not apply to the unoccupied heating and cooling setpoints. When the controller is in the unoccupied mode, it always uses the unoccupied heating and cooling setpoints. Unit configuration enables or disables the local setpoint. This parameter provides additional flexibility to allow you to apply communicated, local, or default setpoints without making physical changes to the unit. Similar to local setpoints, the effective setpoint value for a communicated setpoint is determined based on the stored default setpoints, configuration values, and the controller occupancy mode.



Appendix B

Symbio™ 700 Configuration (Odyssey)

The following table describes the Symbio 700 configuration and options available with reference to the Odyssey Condenser (TTA, TWA) model number and Air Handler (TWE) model number.

Symbio 700 Configuration Item	Symbio 700 Configuration Option	Trane Model Number	Description
System Type	CVZT	Air Handler Digit 15 = 1, C	Air handler, supply fan operation at 1-speed or 2-speeds, zone temperature control or thermostat control.
	VVZT	Air Handler Digit 15 = D	Air handler, Variable speed supply fan zone temperature control (single zone vav).
Space Controller	Conventional TStat	Air Handler Digit 15 = 1, C	Equipment is being controlled from a thermostat in the space.
	Dual Setpoint Zone Sensor	Air Handler Digit 15 = D	Dual (heating and cooling) setpoint zone sensor installed. Applicable to CVZT and VVZT System Type.
	Single Setpoint Zone Sensor	Air Handler Digit 15 = D	Single setpoint zone sensor installed. Applicable to CVZT and VVZT System Type.
Indoor Fan Type	Single Speed	Air Handler Digit 15 = 1	Air handler has a 1-speed supply fan motor.
	Multi Speed	Digit 15 = C	Air handler has a Variable Frequency Drive setup for 2-speed supply fan operation.
	Variable Speed	Digit 15 = D	Air Handler as a Variable Frequency Drive (VFD) setup for variable speed operation.
Refrigeration System	Cooling Only	Condenser Digit 1, 2, 3 = TTA	Direct expansion cooling unit with or without primary heating capacity.
	Heat Pump	Condenser Digit 1, 2, 3 = TWA	Direct expansion heat pump unit with or without secondary heating capacity.
Refrigerant	R-22	Condenser Digit 7	Equipment designed for R-22 refrigerant.
	R-410A	Condenser Digit 7 = 4	Equipment designed for R-410A refrigerant.
	R-454B	Condenser and Air Handler Digit 7 = K	Equipment designed for R-454B refrigerant.
Tonnage (60 Hz)	6	Condenser Digit 4, 5, 6 = 072	Designates the equipment capacity in tons of cooling for 60Hz units.
	7.5	Digit 4, 5, 6 = 090	
	10	Digit 4, 5, 6 = 120	
	12.5	Digit 4, 5, 6 = 150	
	15	Digit 4, 5, 6 = 180	
	20	Digit 4, 5, 6 = 240	
	25	Digit 4, 5, 6 = 300	

Symbio 700 Configuration Item	Symbio 700 Configuration Option	Trane Model Number	Description
Tonnage (50 Hz)	5	Condenser Digit 4, 5, 6 = 060	Designates the equipment capacity in tons of cooling for 50Hz units.
	6.25	Digit 4, 5, 6 = 076	
	8.33	Digit 4, 5, 6 = 101	
	10.4	Digit 4, 5, 6 = 126	
	13.0	Digit 4, 5, 6 = 156	
	16.7	Digit 4, 5, 6 = 201	
	20.9	Digit 4, 5, 6 = 251	
Refrigeration Circuit	Single	Condenser Digit 9 = 1	1 compressor, 1 line, 1 stage
	Single Manifold	Digit 9 = 2	2 compressor, 1 line, 2 stage
	Dual	Digit 9 = D	2 compressor, 2 line, 2 stage
Voltage (60 Hz)	208/230/60	Condenser Digit 8 = 3	208 Vac or 230 Vac, 60Hz, 3-phase
	380/60	Digit 8 = K	380 Vac, 60Hz, 3-phase
	460/60	Digit 8 = 4	460 Vac, 60Hz, 3-phase
	575/60	Digit 8 = W	575 Vac, 60Hz, 3-phase
Voltage (50 Hz)	380/415/50	Condenser Digit 8 = C, D	380 Vac or 415 Vac, 50Hz, 3-phase
Efficiency	Standard	Condenser Digit 14 = A (Generation A)	Efficiency Generation = A, validate by Model number digit 14 = A.
	Standard B	Condenser Digit 14 = B (Generation B)	Efficiency Generation = B, validate by Model number digit 14 = B.
Evaporator Defrost Control	Disabled	—	Air Handler EDC (evaporator defrost control) switch is not installed.
	Enabled	—	Air Handler has an installed and wired EDC switch.
Primary Heating Source	Not Installed	—	No primary heating installed.
	Electric	—	Cooling only condensing unit with primary electric heat installed in the air handler.
	Heat Pump	Condenser Digit 1, 2, 3 = TWA	Heat Pump condenser
Primary Heating Type	Not Installed	—	No primary heat installed (Primary Heating Source = Not Installed)
	Staged	Heat Pump Condenser Digit 1, 2, 3 = TWA or Cooling Only Condenser Digit 1, 2, 3 = TWA and Air Handler has staged electric heat installed	Heat Pump Condenser or Cooling only Condenser with staged electric heat installed in the Air Handler.
Primary Heating Stages	1	—	Heat Pump Condenser or Cooling only Condenser with an Air handler 1-stage electric heat installed.
	2	—	Cooling only Condenser with an Air handler 2-stage electric heat installed.
Secondary Heating Source (Applicable to Heat Pump Condensers)	Not Installed	—	No primary heating installed.
	Electric	—	Heat Pump Condenser with an Air handler stage electric heat installed.



Appendix B

Symbio 700 Configuration Item	Symbio 700 Configuration Option	Trane Model Number	Description
Secondary Heating Type	Not Installed	—	Heat Pump Condenser with no electric heat installed in the air handler.
	Staged	—	Heat Pump Condenser with electric heat installed in the air handler.
Secondary Heating Stages	1	—	Heat Pump Condenser with an Air handler 1-stage electric heat installed.
	2	—	Heat Pump Condenser with an Air handler 2-stage electric heat installed.
Outside Air	Not Installed	—	No outdoor air damper installed, or a manual damper installed.
	0 to 50% Motorized Damper	—	0 to 50% Motorized damper installed
	0 to 100% Economizer	—	0 to 100% Economizer damper installed
Economizer Type	Dry Bulb	—	0 to 100% Economizer damper installed. Economizer cooling operation enables based on outdoor air temperature (dry bulb).
	Differential Dry Bulb	—	0 to 100% Economizer damper installed. Economizer cooling operation enables based on outdoor air temperature and space temperature difference.
	Reference Enthalpy	—	0 to 100% Economizer damper installed. Economizer cooling operation enables based on outdoor air temperature and outdoor air humidity.
	Comparative Enthalpy	—	0 to 100% Economizer damper installed. Economizer cooling operation enables based on outdoor air temperature and outdoor air humidity (enthalpy) vs. return air temperature and return air humidity (enthalpy).
Demand Controlled Ventilation	Disabled, Enabled	—	0 to 100% Economizer damper installed. Demand Controlled Ventilation is a 0 to 100% economizer damper option when a Space CO ₂ sensor is installed.
Remote Minimum Position	Not Installed	—	0 to 100% Economizer damper installed and Customer Connection Options Module not installed.
	Installed	—	0 to 100% Economizer damper installed. Customer Connection Options Module installed with J18 wired to a potentiometer.
Space Pressure Control	Not installed	Digit 11 = 0, 1	Not installed, or Barometric Relief
	Relief Fan Only	Digit 11 = 2, 3, 7, 8, 9	Power Exhaust Fan with 0 to 100% Economizer installed.
FroStat	Not Installed	—	FroStat not installed
	Installed	—	FroStat installed
Humidity Sensor	Not Installed	—	Not installed
	Installed	—	Space Humidity Sensor installed.
CO ₂ Sensor	Not Installed	—	Not installed
	Installed	—	Space CO ₂ Sensor installed.
Discharge Temperature Sensor	Not Installed	—	Not installed
	Installed	—	Air Handler has a Discharge Air Temperature Sensor installed
External Auto/Stop	Not Installed	—	Not installed
	Installed	—	External Auto/Stop binary input installed, requires a Customer Options Module.
Ventilation Override	Not Installed	—	Not installed
	Installed	—	Ventilation Override installed, requires a Customer Options Module.

Symbio 700 Configuration Item	Symbio 700 Configuration Option	Trane Model Number	Description
Alarm Indicator	Not Installed	—	An installed Alarm Indicator requires a Customer Options Module.
	Installed	—	Customer Options Module installed. Alarm Indicator on J10-1, J10-2 normally open binary output.
Demand Management	None	—	Symbio 700 Demand Shed/Demand Limit binary input (J16) is disabled.
	Demand Limit	—	Symbio 700 binary input (J16) enables and disables energy Demand Limit function. See “Demand Limit,” p. 35.
	Demand Shed	—	Symbio 700 binary input (J16) enables and disables energy Demand Shed function. The Demand Shed is enabled, space heating and cooling setpoints will be offset 4°F (default setting).
Supply Air Tempering	Disabled	—	Disabled, Supply Air Tempering functional is disabled.
	Enabled	—	Enabled, Supply Air Tempering function is allowed.



Notes

Trane - by Trane Technologies (NYSE: TT), a global innovator - creates comfortable, energy efficient indoor environments for commercial and residential applications. For more information, please visit trane.com or tranetechnologies.com.

Trane has a policy of continuous product and product data improvements and reserves the right to change design and specifications without notice. We are committed to using environmentally conscious print practices.